

LWMS Series



How can we improve our assembly instructions? Your comments and suggestions are important to us. Please e-mail us at: support@versatables.com.












Support:

Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109 Support@VersaTables.com

Hardware & Parts List

Laptop Wall Mount Computer Station





















10/32 Thumb Nut



Additional Tools Required















Support: Local: 310-353-7100 Toll Free: 888-929-0322


Fax: 310-353-7109 Support@VersaTables.com

Laptop Wall Mount Computer Station

Step

Pre-mark Cabinet Holes

Use Cabinet to premark the places where (4)holes will be drilled to use toggler and bolts to secure it to the wall.



Step

A: Drill a 1/2" hole. Slide Metal Anchor of Toggler through hole. Minimum clearance behind wall is 1-7/8".


Toggler Qty:4

B: Pull end of Toggler until Metal Anchor is flush against inside of wall. Push Plastic Collar into wall to lock in place.




C: Snap exposed material off, flush with Plastic Collar.


NOTE: Togglers are given for mounting to drywall only. If mounting to wood, use Stud Screws.






NOTE: Extra Toggle Bolts are provided

















Support: Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109

Support@VersaTables.com

Laptop Wall Mount Computer Station

Step

L Pieces Set.

10/32 x 3/8 Carriage Bolt

Qty:4

10/32 Thumb Nut



Qty:4

12 SS Washer

Qty:4

Slide Top Short L Piece as shown and secure it with its hardware. DO NOT tighten all the way till your Laptop is in place. Use (4)10-32 x 3/8 Carrige Bolts, (4) 10/32 Thumb Nuts and (4) 12 SS Washers.



Step

L Pieces Set.

10/32 x 3/8 Carriage Bolt

10/32 Thumb Nut



Qty:4

Qty:4

12 SS Washer

Qty:4

Place L Pieces set hardware as shown. DO NOT tighten all the way till your Laptop is in place. Use (4)10-32 x 3/8 Carrige Bolts, (4) 10/32 Thumb Nuts and (4) 12 SS Washers.













Support:

Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109

Support@VersaTables.com

Laptop Wall Mount Computer Station

Step 5

Long L Piece.

10/32 x 3/8 Carriage Bolt

Qty:2

10/32 Thumb Nut



Qty:2 12 SS

Washer

Qty:2

Place Long L Piece hardware as shown. DO NOT tighten all the way till your Laptop is in place. Use (2)10-32 x 3/8 Carrige Bolts, (2) 10/32 Thumb Nuts and (2) 12 SS Washers.




NOTE: Long L Pieces are placed in the back of the unit where the Laptop sits to prevent the Laptop from falling off when stored.

Step

L Pieces Placement

It is recommended to place L Pieces as shown to secure your Laptop. Notice the difference between the Log L Pieces and L Pieces Set placement.



Carriage Bolt Head as shown to be able to place the L Piece Set as shown and adjust them according to your Laptop size.











Support:

Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109 Support@VersaTables.com

Laptop Wall Mount Computer Station






Secure LWMS to wall

Secure Laptop

50mm Furniture Bolt


Qty:4

Attach LWMS Cabinet using (4) 50mm Furniture Bolts. Insert Bolts half way then drop Cabinet onto Bolts and tighten.



Step

Firmly tight Thumb Nuts to avoid laptop from slipping when door closes.











Support: Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109 Support@VersaTables.com

Laptop Wall Mount Computer Station


HINGE REPLACEMENT

Step 1a



Hinge Removal


Unscrew Phillips Head Bolt and remove Hinge.



Step 2

Hinge Placement

Place new Hinge back and Screw Phillips Head Bolt.



How can we improve our assembly instructions? Your comments and suggestions are important to us. Please e-mail us at: support@versatables.com.











Support: Local: 310-353-7100 Toll Free: 888-929-0322

Fax: 310-353-7109 Support@VersaTables.com