VersaTables
INNOVATIVE COMPUTER FURNITURE

Deluxe Diagnostic Fusion Cart
DDFC

Monitor Arm
Fully Adjustable

Keyboard Surface
Fully Articulating

CPU Holder

How can we improve our assembly instructions?
Your comments and suggestions are important to us.
Please e-mail us at: support@versatables.com

Step 12 — Utility / Printer Bracket

Attach the Utility / Printer Bracket to Cart at the desired height using (1) Clamp Bracket and (2) 3/8-16 x 1" Socket Head Bolts.

3/8 -16 x 1"
Socket Head Bolt

Qty: 2

3/8 -16 x 1" Socket
Head Bolt

VersaTables.com
14105 Avalon Blvd.
Los Angeles, CA 90061

LIFETIME WARRANTY
Lifetime Warranty

Quantity Discounts
Quantity Discounts

Buy American Act Compliant
Assembled in USA

Fast Shipping

Support:
Local: 310-353-7100
Toll Free: 888-929-0322
Fax: 310-353-7109
Support@VersaTables.com

8mm Phillips Machine Screw	4mm & 8mm Allen Wrench	20mm Furniture Bolt	1/2 - 13 Jam Nuts	Caster & Caster with Lock
Qty:4	Qty:2	Qty:6	Qty:4	Qty:4

Base	Upright Extension	Keyboard Arm	Zip Tie & Curly Tie	
Qty:1	Qty:1	Qty:1	Qty:5	

Keyboard Platform	Push Handle	LCD Holder	CPU holder	
Qty:1	Qty:1	Qty:1	Qty:1	

Clamp Bushing	3/8 - 1/6 x 1" Socket Head Bolt	CPU Holder Mount Bracket	Clamp	1" 7/8 Velcro Pads 1 Velcro Loops 1 Velcro Hooks
Qty:2	Qty:2	Qty:1	Qty:1	Qty:2

Additional Tools Required

Phillips Screw Driver (Optional)	3/4" Wrench

VersaTables.com
14105 Avalon Blvd.
Los Angeles, CA 90061

Lifetime Warranty   Quantity Discounts   Assembled in USA   Fast Shipping

Support:
Local: 310-353-7100
Toll Free: 888-929-0322
Fax: 310-353-7109
Support@VersaTables.com

Monitor Arm

Keyboard Surface

Upright Extension

Push Handle

Keyboard Arm

Clamp

CPU holder

Base

Caster with Lock

Caster

Step 1 — Attach Casters to Base

1/2-13 Jam Nut
Qty:4

Use the Jam Nut to insure a level and stable base. Tighten with 3/4"Wrench.

Caster

1/2-13 Jam Nut

Caster with Lock

NOTE: The Casters with Locks are installed in the front of the Base.

## Step 2 — Attach Upright Extension to Base

20mm Furniture Bolt
Qty:4

Attach Upright Extension using four 20mm Furniture Bolts. Tighten with 4mm Allen Wrench.

NOTE: Lock Casters to keep cart from moving during the rest of the assembly.

20mm Furniture Bolt

VersaTables.com
14105 Avalon Blvd.
Los Angeles, CA 90061

LIFETIME WARRANTY — Lifetime Warranty
Quantity Discounts — Quantity Discounts
Buy American Act Compliant — Assembled in USA
Fast Shipping

Support:
Local: 310-353-7100
Toll Free: 888-929-0322
Fax: 310-353-7109
Support@VersaTables.com

Step 3 — Attach mount bracket to CPU holder

Use (2) 20mm Furniture Bolts.

20mm Furniture Bolt

Qty: 2

NOTE: If necessary, loosen the two stoppers and lower bottom piece to expose the mounting holes

mounting holes

loosen and lower

Step 4 — Attach CPU Holder At the desired Height.

Use (1) Clamps and (2) 3/8 1/6 x 1" Socket Head Bolts.

Clamp

Qty: 1

3/8 1/6 x 1" Socket Head Bolt

Qty: 2

Clamp Bushing

Qty: 2

VersaTables.com
14105 Avalon Blvd.
Los Angeles, CA 90061

LIFETIME WARRANTY
Lifetime Warranty

Quantity Discounts
Quantity Discounts

Buy American Act Compliant
Assembled in USA

Fast Shipping

Support:
Local: 310-353-7100
Toll Free: 888-929-0322
Fax: 310-353-7109
Support@VersaTables.com

Step 5 — Attach Velcro Pads to both your CPU and CPU Holder.

Once in place, adjust Holder and tighten Thumb Nuts to keep CPU secure.

Velcro Pads

Qty: 2

Velcro

CPU holder Adjustability

Height

Width

VersaTables.com
14105 Avalon Blvd.
Los Angeles, CA 90061

LIFETIME WARRANTY — Lifetime Warranty

Quantity Discounts — Quantity Discounts

Buy American Act Compliant — Assembled in USA

Fast Shipping

Support:
Local: 310-353-7100
Toll Free: 888-929-0322
Fax: 310-353-7109
Support@VersaTables.com

Step 6

Attach Push Handle

Slide Upright Extension to desired height and tighten Pull Pin. Once in place, slide Push Handle onto Upright Extension and tighten T-Knob

Tighten T-Knob

Tighten Pull Pin

Step 7

Assemble Keyboard Surface.

Lay Keyboard Surface Upside Down and attach Keyboard Arm.

3/4 Phillips Pan Head Screw

Qty:6

3/4 Phillips Pan Head Screw

Keyboard Surface

NOTE: Some holes will not be used due to multiple configurations.

NOTE: Align back of Keyboard Surface to back of Keyboard Arm mounting surface.

VersaTables.com
14105 Avalon Blvd.
Los Angeles, CA 90061

LIFETIME WARRANTY
Lifetime Warranty

Quantity Discounts
Quantity Discounts

Buy American Act Compliant
Assembled in USA

Fast Shipping

Support:
Local: 310-353-7100
Toll Free: 888-929-0322
Fax: 310-353-7109
Support@VersaTables.com

Step 8

Slide Keyboard Arm onto Upright Extension and Tighten T-Knob

Attach Keyboard Arm

Step 9

Slide Monitor Arm onto Upright Extension and tighten T-Knob.

Assemble Keyboard Surface.

Step 10 — Attach Monitor.

Attach your monitor to the LCD holder using four 8mm Phillips Machine Screws. Make sure to tighter Pull Pin.

8mm Phillips Machine Screw

Qty:4

8mm Phillips Machine Screw

Tighten Pull Pin

NOTE: Steps 10 and 11 are OPTIONAL. The Utility / Printer Platform is an ADDITIONAL ACCESSORY and is acquired separately from the cart.

Step 11 — Utility / Printer Platform

Attach the Utility / Printer Platform to Utility Bracket using (4) 1/4-20 Phillips Head Bolts.

1/4-20 Phillips Head Bolt

Qty:4

1/4 - 20 Phillips Head Bolt

LIFETIME WARRANTY — Lifetime Warranty

Quantity Discounts — Quantity Discounts

Buy American Act Compliant — Assembled in USA

Fast Shipping