

Split Level Classroom Table

Assembly Instructions



How can we improve our assembly instructions? Your comments and suggestions are important to us. Please e-mail us at: support@versatables.com.











Support:

Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109 Support@VersaTables.com

Hardware & Parts List

Split Level Classroom Table



























OPTIONAL











Support: Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109

Support@VersaTables.com


Split Level Classroom Table

Step 1 Levelers

Insert Levelers into Bottom Frames L & R.



Qty:4






Step 2 Attach Cable Management Tray

Insert 2 20mm Furniture Bolts to each Bottom Frame half way. Then drop Cable Management tray unto screws and tighten.



Qty:4














Support: Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109 Support@VersaTables.com

Split Level Classroom Table

Step 3 Attach Kick Panel

Direct Kick Panel to Bottom Frame and attach it using (4) 20mm Furniture Bolts.



Step 4


Top Frames

Turn and pull to adjust the height, turn clockwise

Slide Top Frames.

to lock pop-pin.
Once a platform is at desired height, turn pop-pin

mechanism to tight and secure the table.











Support:

Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109 Support@VersaTables.com


Split Level Classroom Table

Step 5

Cross Supports

Attach Cross Supports to Frames using (2) 20mm Furniture Bolts per Cross Support.





Step

6

Main and Back Platforms

Place Main and Back Surfaces on top of frames. Attach them with (4) 50mm Furniture Bolts on each Surface.



Qty:8













Support: Local: 310-353-7100

Toll Free: 888-929-0322 Fax: 310-353-7109 Support@VersaTables.com

Split Level Classroom Table

Step

NOTE: Steps 7 is optional in case ECPU Holders are ordered.

ECPU Holder

Insert ECPU Holder into Kickpanel notches and slide in cpu tower.











Support:

Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109

Support@VersaTables.com