

#### Universal Table Mount Monitor Arm UTMM-R1

## **Assembly Instructions**



How can we improve our assembly instructions? Your comments and suggestions are important to us. Please e-mail us at: support@versatables.com.











Support:

Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109

## **Hardware & Parts List**

#### Universal Table Mount Monitor Arm










## **Exploded View**













Support:

Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109

Support@VersaTables.com

# **Assembly Step-byStep**

#### Universal Table Mount Monitor Arm

Step


**Wood Grommet** 

Remove Wood Grommet.



Step 2 16" Pole

Insert 16" Pole to Grommet cutout. From underneath the surface screw on Lock Nut, teeth facing upward. Then turn the Pole to tighten and place cutout where desired.











Support:

Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109 Support@VersaTables.com


### **Assembly Step-byStep**

#### **Universal Table Mount Monitor Arm**

Step

Monitor Arm

Slide Monitor Arm on to 16" Pole and tighten in place with 'T' knob.



Step


**LCD** Monitor


Attach LCD monitor to the Vesa Plate with (4) 8mm Phillips Machine Screws.



Qty:4

8mm Phillips Machine Screw





How can we improve our assembly instructions? Your comments and suggestions are important to us. Please e-mail us at: support@versatables.com.











**Support:** 

Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109 Support@VersaTables.com