

Revolution Desk Series

Assembly Instructions

RSD 36", 48", 60" & 72"



How can we improve our assembly instructions? Your comments and suggestions are important to us. Please e-mail us at: support@versatables.com.











Support:

Hardware & Parts List

Revolution Desk Series



Qty:4



4mm Allen Wrench Qty:1





8mm LCD Flat Screen Mounting Screw



Qty:4 for 36" & 48" Qty:8 for 60" & 72"



Main Platform with Built in Cross Support







Qty:4 for 36" & 48" Qty:8 for 60" & 72"





3/16" Spacer



Qty:4 for 36" & 48" Qty:8 for 60" & 72"





Cable Management tray

3/4" Phillips Pan Head Screw



Qty:4 for 36" & 48" Qty:8 for 60" & 72"



Qty:2



Cable Management Clip



Qty:3 for 36" & 48" Qty:6 for 60" & 72"

















Support: Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109 Support@VersaTables.com

Qty:1

Quantity Discounts

Assembled in USA

Hardware & Parts List

Revolution Desk Series

CPU-STAND IS INCLUDED JUST for Revolution Desk Series 36" & 60"


























Support:

Revolution Desk Series















Support:

Revolution Desk Series















Support: Local: 310-353-7100 Toll Free: 888-929-0322

Fax: 310-353-7109 Support@VersaTables.com

ed in USA Fast Shipping

Revolution Desk Series


Step

LCD Monitor

Main Platform

Attach LCD Monitor to surface using (4) 3/4" Phillips Pan Head Screw on each Monitor.





Step

20mm

Place Main Surface on top of frame assembly with Cross Support facing forward and attach with 4 1/4-20 (Silver) Phillips Head Bolts. For the Cross Support use (4) 20mm (Black) Furniture Bolts.




Furniture Bolt

Qty:4



1/4-20 Phillips













Support: Local: 310-353-7100 Toll Free: 888-929-0322

Fax: 310-353-7109 Support@VersaTables.com

Lifetime Warranty

Quantity Discounts Assembled in USA

Revolution Desk Series

Step

Wire Management Clips

Cable
Management
Clip

 Insert Wire Management Clips to Channels on surface and run cables and extenders through for a cleaner look.







Step

8

Keyboard Tray

Hold and Place Keyboard Tray under the Main Platform.













Support:

Revolution Desk Series

Step

9

Enclosed CPU Holder


Insert CPU Holders into Kick Panel Slots.



Step 10

CPU Tower Placement

Insert and place CPU Tower in holders. Use Thumb Screws to adjust fitting size of CPU Holder.













Support: Local: 310

Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109

Support@VersaTables.com

Quantity Discounts A

Assembled in USA Fast S

Revolution Desk Series

NOTE: Steps 11 to 15 belong to the CPU-STAND Assembly

Included with 36" and 60" wide units only.



There are three possible configurations.

NOTE: Extender is shown in a bluish color to help you see when it is used.





Extender (To be used for CPU towers over 6" Wide)









Support:


Revolution Desk Series



Secure First and Second L Panel

Use (4)10-32 x 3/8 Carrige Bolts, (4) 10/32 Thumb Nuts and (4) 12 Nylon Washers.





Step 12

Casters

Attach Casters or 5/16" Gliders as needed.















Support: Local: 310




Secure Second L Panel Assembly

Use (2)10-32 x 3/8 Carrige Bolts, (2) 10/32 Thumb Nuts and (2) 12 Nylon Washers.




Qty:2



Step 13b Performed when CPU towers over 6" Wide. Secure Second L Panel Assembly

Use (2)10-32 x 3/8 Carrige Bolts, (2) 10/32 Thumb Nuts and (2) 12 Nylon Washers.















Support:

Revolution Desk Series

Step 1

Velcro Pads

Velcro Pads

Attach Velcro Pads to both your CPU Tower and CPU Stand, then slide in CPU Tower.



Qty:4









Step 15



CPU-STAND

Slide CPU-STAND and place it where needed.





How can we improve our assembly instructions? Your comments and suggestions are important to us. Please e-mail us at: support@versatables.com.











Support: