


## Pole Mount Dual Monitor Arm **PMDMA**

## **Assembly Instructions**



How can we improve our assembly instructions? Your comments and suggestions are important to us. Please e-mail us at: support@versatables.com.













**Support:** Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109 Support@VersaTables.com

## **Hardware & Parts List**

### Pole Mount Dual Monitor Arm












# **Assembly Step-byStep**














Support: Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109 Support@VersaTables.com

Pole Mount Dual Monitor Arm


Step 1

Remove Wood Grommet.



Step 2

Insert 16" Pole to Grommet cutout. From underneath the surface screw on Lock Nut, teeth facing upward. Then turn the Pole to tighten and place cutout where desired.














Support: Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109 Support@VersaTables.com

## **Assembly Step-byStep**

Step


Slide Monitor Arm on to 16" Pole to desired height and tighten it in place with 'T' knob.

Slide in the LCD Holders from each end of the Monitor arm to desired location and tighten them in place with 'T' Knob



8mm Screw

Attach LCD monitor to the LCD Holders with (8) 8mm Phillips Machine Screws.







**Quantity Discounts** 





**Support:** Local: 310-353-7100

Toll Free: 888-929-0322 Fax: 310-353-7109 Support@VersaTables.com