

# Signature Series Desk SSD 48", 60" & 72"

### **Assembly Instructions**



How can we improve our assembly instructions? Your comments and suggestions are important to us. Please e-mail us at: support@versatables.com.











**Support:** 

### **Hardware & Parts List**

#### Signature Series Desk


























# **INCLUDED JUST for Signature Series Desk 48"**












Support: Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109

Support@VersaTables.com

### Signature Series Desk











Fast Shipping

Support: Local: 310

Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109

Support@VersaTables.com

#### Signature Series Desk

Step 1


### NOTE: Steps for SSD60 & SSD72

**Fillers** 

20mm Furniture Bolt

Qty:6

Attach Fillers to back side of Pedestals using (6) 20mm Furniture Bolts, 3 per Pedestal.




Step 2

Cable Management Tray

20mm Furniture Bolt

Qty:4

Insert 20mm Furniture Bolts to bottom of Filler half way and then drop Cable Management Tray onto extended screws and tighten them using the Allen Wrench.













Support:

#### Signature Series Desk


Step

**Back Panel** 

20mm Furniture Bolt

Qty:4

Insert 20mm Furniture Bolts to Back Panel half way and then drop through key holes in Filler and tighten them using the Allen wrench.




Step 2

**Button** 

Head Bolt

Angle Brackets

Attach the Angle Brackets to the left and right side of Pedestals using (12) Button Head Bolts.













Support:

### Signature Series Desk

Step


Main Surface

**Button** 

Attach Main Surface to the (4) Angle Brackets using Button Head Bolts (3 per bracket).



Note: Please make sure to use only Button Head Bolts. They are slightly smaller than the 20mm Furniture Bolts to prevent damage to the surface.



How can we improve our assembly instructions? Your comments and suggestions are important to us. Please e-mail us at: support@versatables.com.











Support: Local: 310-353-7100 Toll Free: 888-929-0322 Fax: 310-353-7109

Support@VersaTables.com


#### Signature Series Desk

Step 1a

### NOTE: Steps for SSD48 L or R

**Fillers** 

Attach Filler to back side of Pedestal using (3) 20mm Furniture Bolts.




Step 2a

Cable Management Tray

20mm Furniture Bolt

Qty:4

Insert 20mm Furniture Bolts to bottom of Filler and Side Panel half way and then drop Cable Management Tray onto extended screws and tighten them using the Allen Wrench.













Support:

#### Signature Series Desk


Step 3a

**Back Panel** 

20mm Furniture Bolt

Qty:4


Insert 20mm Furniture Bolts to Back Panel half way and then drop through key holes in filler and tighten them using the Allen wrench.



Step 4a

Button Head Bolt Angle Brackets

Attach the Angle Brackets to the left and right side of Pedestal using (6) Button Head Bolts.













#### Signature Series Desk

Step 5a

Main Surface

Attach Main Surface to the (2) Angle Brackets using Button Head Bolts (3 per bracket).

Button Head Bolt

Note: Please make sure to use only Button Head Bolts. They are slightly smaller than the 20mm Furniture Bolts to prevent damage to the surface.



How can we improve our assembly instructions? Your comments and suggestions are important to us. Please e-mail us at: support@versatables.com.











Support: Local: 310-353-7100 Toll Free: 888-929-0322

Fax: 310-353-7109 Support@VersaTables.com