
1. Turning on the simulator


- Click the power button on the PC
- Make sure power to both monitors are on
- The simulator should automatically load into a flight after about 2 - 4 minutes
- If it does not load into a flight refer to step #2



2. Program crash or not loading


- Double click on the program named Flight Simulator on the small monitor using the keyboard/mouse
- If given option to load into safe mode click “No Thanks”
- Program should continue loading normally into a flight






3. Selecting a different flight scenario

- There are 3 different flight scenarios
  - Fighter Jet (Default)
  - Passenger Jet
  - Small Plane
- Select ‘Load Flight’
- Select flight scenario
- Selected ‘Load Selected Flight’







Fighter Jet




Passenger Jet




Small Plane

4. Flying and controls


- To fly the plane there are four main controls:
  - Throttle
  - Roll
  - Pitch
  - Yaw
- A basic understanding is necessary to fly
- Movements on the joystick control the aircraft flight and direction, like shown in the photo






4. Flying and controls cont.

1. Change aircraft view (cockpit, outside, etc.)
2. Rotate outside view (left/right)
3. Rotate outside view (up/down)
4. Look around inside cockpit



4. Flying and controls cont.

1. Parking brake (must be toggled every flight in order to take off)
2. Flaps up
3. Flaps down
4. Landing gear toggle
5. Speed (air) brake toggle




4. Accessories and lighting

- Sound may be controlled directly via the PC or through the volume knob on the speakers
- There are two lighting modes:
  - Cockpit lights
  - Floor lights







4. Shutting down simulator

- Use may use ALT + F4 to leave the simulator program or the ‘Exit X-Plane’ button
- Shutdown PC normally
- Turn off all other monitors, displays, lights, etc. accordingly