


NOTE: Complete the rest of this page for both the Standard and Quickbuild Kits.


Step 2: Final-Drill #40 and dimple the holes in the F-10100B Baggage Door Shim and F-1026 Lower Baggage Door Seal Channel which are common to the F-1070-L and F-1073-L Side Skins. See Figure 2. The baggage door shim is not symmetrical, be sure to dimple in the correct direction.

<u>Step 3:</u> Cleco the F-1026 Lower Baggage Door Seal Channel and the F-10100B Baggage Door Shim to the F-1070-L and F-1073-L Side Skins as shown in Figure 2. Cleco the two end-tabs of the lower baggage door seal channel to the F-1006A Bulkhead and the F-1022A-L Baggage Floor.

<u>Step 4:</u> There are two holes in the bottom end-tab of the F-1026 Lower Baggage Door Seal Channel. Match-Drill #30 the inboard hole into the F-1022A-L Baggage Floor and final-drill the outboard hole.

Final-Drill #30 the two holes common to the top end-tab of the lower baggage door seal channel and the F-1006A Bulkhead.





<u>Step 6:</u> Final-Drill #30 the hole in the outboard flange of the F-1031 Upper Baggage Door Seal Channel which is common to the outboard hole in the end tab of the F-1026 Lower Baggage Door Seal Channel. See Figure 4.


Step 7: Cleco the F-1031 Upper Baggage
Door Seal Channel to the F-1006A
Bulkhead and F-1026 Lower Baggage
Door Seal Channel as shown in
Figure 4.

Step 8: Cleco the F-1027 Close-Out Panel to the F-1026 Lower Baggage Door Seal Channel and the F-1006A Bulkhead.

Step 9: Match-Drill #30 the holes in the lower flange of the F-1027 Close-Out Panel into the F-1022A-L Baggage Floor.

Final-Drill #30 the holes common to the vertical flange of the close-out panel and the F-1006A Bulkhead, and the holes common to the closeout panel and the F-1026 Lower Baggage Door Seal Channel.

Step 10: Final-Drill #30 the holes common to the F-1031 Upper Baggage Door Seal Channel and the F-1006A Bulkhead.








FIGURE 1: SEPARATING THE F-1022 BAGGAGE FLOOR STIFFENERS

Step 2 (Standard and Quickbuild Kit): Remove from the fuselage all of the parts clecoed in this section.

NOTE: Complete the rest of this page for the Standard Kit only.

<u>Step 3:</u> As shown in Figure 2, cleco the F-1022 Baggage Floor Stiffeners to the bottom of the F-1022A-L and -R Baggage Floors (only the right baggage floor is shown in the figure), then final-drill #40 the holes common to the parts.







<u>Step 7:</u> Dimple the #40 nutplate attachment rivet holes near the outboard edge of both F-1024 Seat Floors (see Figure 4). Do not dimple the #19 holes.


<u>Step 8:</u> Dimple the holes along the forward edge of both F-1024 Seat Floors (see Figure 4) and the common holes in the underlying flange of the F-1005A Rear Spar Bulkhead. The #19 holes are dimpled for AN509 flush head screws.


Step 9: Dimple the #30 and #40 holes along the inboard edge of both F-1024 Seat Floors (see Figure 4) and the common holes in the underlying flange of the F-1017A Rear Seat Ribs. Do not dimple the #19 holes.

Step 10: There are nutplate hole patterns punched in the top flange of the F-1005A and F-1034A Bulkheads between the F-1024 Seat Floors. Of these holes, dimple the #40 holes in the F-1034A Bulkhead and the #40 and #19 holes in the F-1005A bulkhead.









VAN'S AIRCRAFT, INC.

<u>Step 1:</u> Remove the tab from the top flange of the F-1080 Right Baggage Cover as indicated in the blowup of Figure 1 (for clarity the F-1034B Seatback Brace is not shown).

Step 2: Cleco the forward end of the F-1080 Right Baggage Cover to the F-1034C-R Fuselage Bulkhead.

<u>Step 3:</u> There are four holes in the forward flange of the F-1028 Baggage Bulkhead Channel. Draw a line down the entire flange centered on these holes, then dimple the holes for the dimples in the F-1006D Bulkhead.

Step 4: Using only the top two holes in the forward flange of the F-1028 Baggage Bulkhead Channel, cleco the flange to the F-1006D Bulkhead. Rivet the bottom end of the baggage bulkhead channel to the F-1029-R Bellcrank Rib using the rivets called-out in the blow-up of Figure 1. (The top end is riveted after the Cabin Cover is installed in a later section.)

<u>Step 6:</u> Temporarily secure the bottom of the F-1006F Lower Baggage Bulkhead Corrugation to the aft flange of the F-1022A Baggage Floors using the screws called-out in Figure 2.

Step 7: Match-Drill #19 the holes along the left side of the F-1006F Lower Baggage Bulkhead Corrugation (the right side is drilled later) into the F-1027 Close-Out Panel, the F-1031 Upper Baggage Door Seal Channel, and the F-1006A Bulkhead. Cleco a few of these holes to secure the lower baggage bulkhead corrugation to the bulkhead.

Match-Drill #19 the three holes of the lower baggage bulkhead corrugation into the F-1028 Baggage Bulkhead Channel. Be sure the line which was drawn on the forward flange of the baggage bulkhead channel remains centered in the holes of the lower baggage bulkhead corrugation while drilling.

