

VAN'S AIRCRAFT, INC. Step 1: Completely disassemble the baggage door assembly, and then deburr the holes in all of the parts. Step 2: Machine countersink the holes in the F-1060 Hinge for the heads of AN426AD3 rivets. Step 3: Dimple the #30 holes in the F-1059F Close-Out Panel and the corresponding holes in the underlying structure. Except for the #40 holes in the F-1059A Forward Frame which are common to the F-1060 Hinge, dimple all #40 holes in the remaining parts. Step 4: Prime the parts if/as desired. NOTE: Refer to Figure 1 for part number references and rivet call-outs required for Steps 5-7. Step 5: Rivet the F-1060 Hinge to the F-1059A Forward Frame. Step 6: Rivet the F-1059A, B, and C Frames to the F-1059E Skin and to each other. Step 7: Rivet the F-1059D Lock Bracket to the F-1059E Skin and to the F-1059B Upper Frame.

AN426AD3-3.5 7 PLACES

PAGE **34-4**

RV-10

F-1059D

F-1059C

-1059B

AN426AD3-3.5

6 PLACES

FIGURE 1: RIVETING THE

BAGGAGE DOOR

REVISION: 1 DATE: 07/24/14

F-1059E

AN426AD3-3.5

ALL F-1060 TO

F-1059A RIVETS


AN426AD3-3.5 6 PLACES

AN426AD3-3.5

F-1059A, B, & C

RIVETS

BAGGAGE DOOR Step 8: Install the Lock and **ASSEMBLY** the F-1062 Lock Latch as F-1062 shown in Figure 2. (The lock OR F-1062-1 and hardware, which is included with the ES A-510-2K Magneto Switch, is not supplied in the kit. They can **SCREW** be ordered from the Van's Accessories Catalog.) Be sure WASHER to install the lock in the Baggage Door Assembly so FIGURE 3: that a clockwise rotation of the key will lock the door as shown **UNLOCKED TABBED** in Figures 3 and 4. Once the **POSITION** WASHER nut for the lock is tightened, bend up one of the tabs on the LOCK tabbed washer to prevent the nut from rotating. To prevent the screw from backing out, apply Locktite to the threads. FIGURE 4: LOCKED FIGURE 2: **POSITION** INSTALLING THE LOCK Step 9: Rivet the F-1059F Close-Out Panel to the F-1059A, B, and C Frames using the rivets called-out in Figure 5. F-1059B CS4-4 ALL F-1059F TO ALL F-1059E TO F-1059A, B, & C **RIVETS** F-1059F F-1059C F-1060 FIGURE 5: RIVETING THE **CLOSE-OUT PANEL**



VAN'S AIRCRAFT, INC.

Step 1: Remove the Baggage Door Assembly and the F-1058 Hinge Frame from the fuselage. Cleco the hinge frame to the F-1060 Hinge using the two holes drilled on Page 34-5, Step 7, then match-drill #40 the remaining holes of the hinge frame into the hinge. Deburr the holes of both parts.

Step 2: Machine countersink the hinge for the heads of AN426AD3 rivets.

REVISION: 0 DATE: 07/24/14

PAGE **34-6**

RV-10

Step 3: Rivet the F-1060 Hinge to the F-1058 Hinge Frame using the rivets called-out in Figure 1.

Step 4: Attach 1/8" thick x 1/4" wide seal material (door and window weather strip tape can be used) to the F-1059E Skin about an 1/8" from the edges of the skin as shown in Figure 1.




FIGURE 1: ATTACHING THE HINGE FRAME AND SEAL

<u>Step 5:</u> Separate the F-1058 Hinge Frame from the baggage door assembly by removing the hinge pin, then rivet the hinge frame to the fuselage using the rivets called-out in Figure 2 (the F-1034B Seatback Brace is not shown).

Step 6: Attach the Baggage Door Assembly to the F-1058 Hinge Frame by reinstalling the hinge pin.

Step 7: Attach the F-1061 Striker Plate to the F-1031 Upper Baggage Door Seal Channel using the hardware shown in Figure 2. Adjust the striker plate as needed to flush the aft end of the Baggage Door Assembly with the fuselage when the door is closed and locked.

