



## VAN'S AIRCRAFT, INC.



NOTE: This page describes the installation of the left brake line between the tunnel and the brake line exit location on the left side of the aircraft. Repeat the steps on this page for the right side of the aircraft. The right installation is a mirror of the left.

Step 1: Using a Unibit enlarge the brake line exit hole in the F-01072-1 Fwd Fuse Bottom Skin to 5/8 diameter as called out in Figure 1.

Step 2: Install the AN837-4D 45° Elbow and AN924-4D Nut onto the WD-01021-1 Landing Gear Mount - Left as shown in Figure 1. Using the gear leg socket as reference, orient the fitting to aim down the gear leg.






FIGURE 2: INSTALLING THE INBD BULKHEAD FITTING

PAGE: 36-2 RV-10 REVISION: 1 DATE 01/07/21

