

NOTE: The instructions on this page show how to install the F-1016C-L Floor Pan. The right installation is a mirror of the

Step 1 (Standard Kit): Force the F-1016-L Outbd Foot Well Rib and the F-1016F-L Inbd Foot Well Rib apart slightly then insert and cleco the F-1016C-L Floor Pan in place. See Figure 2. Final-Drill #30 the holes common between the outbd and inbd foot well ribs and the floor pan. Final-Drill #30 the holes common between the F-1005A Rear Spar Bulkhead and the floor pan. Match-Drill #30 the holes in the forward flanges of the floor pan into the F-1004B Center Section Bulkhead.

Step 2 (Standard Kit): Final-Drill #19 the screw holes and Final-Drill #40 the corresponding nutplate attach holes in the bottom face of the F-1016C-L Floor Pan. Final-Drill #30 the remaining holes in the bottom face of the floor pan. See Figure 1.

under structure in Step 2. Dimple all the rivet holes in the bottom face of the floor pan, see Figure 1. Dimple the screw holes in the bottom face of the floor pan for the head of an #8 screw (flush face on top side). Prime the floor pan if desired. Dimple the nutplates. Step 4 (Standard Kit): Rivet the five nutplates to the bottom side of the F-1016-L Floor Pan per the callouts in Figure 1.

ALL F-1016O-L TO

F-1016B-L OR -R

Step 5 (Standard & Quick Build Kit): Cleco the F-1016C Floor Pan in place then rivet the floor pan to the F-1016 Outbd Foot Well Rib, F-1016F L Inbd Foot Well Rib, F-1005A Rear Spar Bulkhead, and F-1004B Center Section Bulkhead per the callouts in Figure 2. Blind Rivet the floor pan to the F-1016B-L and R Floor Stiffeners per the callouts in Figure 2.





FIGURE 2: FLOOR PAN INSTALLATION



VAN'S AIRCRAFT, INC.

PAGE 35-4

NOTE: This page is for the Standard Kit only! This page describes how to install the F-1025-R Rear Seat Cover Panel. The left installation is a mirror of the right.

Step 1: Final-Drill #19 all the screw holes in the lower flanges, forward flange, and aft flange of the F-1025-R Rear Seat Cover Panel.

Step 2: Deburr then dimple the lower three screw holes in the forward flange of the F-1025-R Rear Seat Cover Panel for the head of an #8 screw. See Figure 1.

Step 3: Install the F-1025-R Rear Seat Cover Panel using the hardware (except the upper flange hardware) called out in Figure 2.

F-1005C-R F-1013-R AN426AD3-5, 2 PLACES PER NUTPLATE DIMPLE F-1024-R K1000-08, 7 PLACES F-1025-R (SHOWN TRANSPARENT)

FIGURE 1: MATCH-DRILLING THE REAR SEAT


COVER PANEL TO THE LONGERON


RV-10 REVISION: 0 DATE: 07/24/14

Step 4: Match-Drill #19 the screw holes in the upper flange of the F-1025-R Rear Seat Cover Panel into the F-1013-R Fwd Fuselage Longeron.

Step 5: Remove then deburr the holes and edges of the F-1025-R Rear Seat Cover Panel. Prime the rear seat cover panel if

Step 6: Using a nutplate as a drill guide match-drill #40 the nutplate attach pattern into the F-1013 R Fwd Fuselage Longeron at each of the seven locations match-drilled in Step 4. Machine countersink these holes for the head of an AN426AD3 rivet on the upper side of the longeron. Deburr all the holes in the longeron drilled in this step and Step 4. Install nutplates to the longeron per the callouts in Figure 1.





NOTE: Complete this page for both the Standard and Quickbuild Kits.

Step 1: Cleco the F-1051C Aft Fuselage Tunnel Cover and F-1051G Splice Plate together as shown in Figure 1.

Step 2: Final-Drill #40 the holes common between the parts clecoed together in Step 1 and both sets of nutplate attach holes along the forward edge of the F-1051G Splice Plate.

Final-Drill #19 both screw holes along the forward edge of the splice plate. Final-Drill #19 all the screw holes along the side and aft flanges of the F-1051C Aft Fuselage Tunnel Cover.

Step 3: Disassemble and deburr all parts. Dimple (flush head on top side) the rivet holes in all the parts. Dimple the screw holes in the F-1051C Aft Fuselage Tunnel Cover and the F-1051G Splice Plate for the head of an #8 screw. Dimple the nutplates. Prime parts if desired.

Step 4: Repeat Step 1 then rivet the parts clecoed together in Step 1, and the two nutplates common to the F-1051G Splice Plate per the callouts in Figure 1. This will create the Aft Tunnel Cover Assembly.






FIGURE 1: AFT FUSE TUNNEL COVER ASSEMBLY

Step 5: Final-Drill #19 the screw holes along the aft edge and side flanges of the F-1051A Fwd Fuselage Tunnel Cover.

Step 6: Deburr the F-1051A Fwd Fuselage Tunnel Cover. Dimple the screw holes in the F-1051A Fwd Fuselage Tunnel Cover for the head of an #8 screw. Prime the Fwd Fuselage Tunnel Cover if desired.

Step 7: Final-Drill #40 and deburr the holes common between the F-1051A Fwd Fuselage Tunnel Cover and VA-178D Detent Plate. Countersink the top side of the Detent Plate, then rivet the Detent Plate to the Fwd Fuselage Tunnel Cover per the callouts in Figure 2.





NOTE: Step 1 and Step 2 describe how to install the F-1016E-1 Flap Torque Tube Cover. The right cover installation is a

NOTE: Step 1 and Step 2 describe how to install the F-1016E Flap Torque Tube Cover. The right cover installation is a mirror of the left.

Step 1: Final-Drill #19 the screw holes in the F-1016E-1 Flap Torque Tube Cover.

NOTE: Complete this page for both Standard and Quickbuild Kits.

Step 2: Deburr the holes and edges of the F-1016F-1 Flap Torque Tube Cover. Dimple the screw holes in the flap torque tube cover for the head of an #8 screw. See Figure 1.




FIGURE 1: INSTALLING THE FLAP TORQUE TUBE COVER

NOTE: The remainder of this page shows the installation of the F-1042G-R Wire Cover. The installation of the left cover is a mirror of the right.

Step 3: Final-Drill #19 the holes in the F-1042GFR Wire Cover. See Figure 2.

Step 4: Deburr the holes and edges of the F-1042GFR Wire Cover. Prime the cover if desired.





FIGURE 2: INSTALLING THE WIRE COVER

VAN'S AIRCRAFT, INC.



NOTE: Complete this page for both the Standard and Quickbuild Kits.

NOTE: This page describes the installation of the <u>F-01067A-1</u> Seat Floor on the left hand side of the aircraft. The right side installation is a mirror of the left.

NOTE: When installing the F-01067A-1 Seat Floors, first slide the cover up underneath the F-01043B-1 Forward Fuselage Bulkhead.

Step 1: Figure 1 shows the final install of the F-01067A-1 Seat Floors, but wait to install them until all systems installations and wiring runs have been completed.




FIGURE 1: INSTALLING THE SEAT FLOORS



NOTE: Complete this page for the Standard Kit Only.

NOTE: This page describes the installation of the F-1015D-R Mid Cabin Side Cover and the right side F-1067B Seat Floor Cover. The installation of the left covers is a mirror of the right.

Step 1: Final-Drill #19 the screw holes in the F-1015D-R Mid Cabin Side Cover and F-1067B Seat Floor Cover. Final-Drill #40 the nutplate attach holes in the mid cabin side cover.

Step 2: Duburr the holes and edges of both the F-1015D-R Mid Cabin Side Cover and F-1067B Seat Floor Cover. Dimple all the screw holes in the mid cabin side cover except the top row of holes and the holes in the forward lower flange (See Figure 1). Dimple the platenut attach holes in the mid cabin side cover. Dimple the platenuts. Machine countersink the screw holes on the inboard face of the F-1015C Mid Cabin Decks. Machinge countersink the locations for the four AN509-8R8 screws shown on Page 35-8, Figure 1. Prime the parts if desired.

Step 3: Rivet the platenuts to the F-1015D-R Mid Cabin Side Cover per the callouts in Figure 1.

NOTE: When installing the F-1015D Mid Cabin Covers, first slide the cover up underneath the F-1015C Mid Cabin Decks then slide the cover down underneath the F-1016 Outbd Foot Well Rib.




FIGURE 2: INSTALLING THE MID CABIN SIDE COVER AND THE SEAT FLOOR COVER

VAN'S AIRCRAFT, INC.



NOTE: This page describes the installation of a F-1050B Bolt Access Plate to the right side of the aircraft. The left installation is a mirror of the right.

Step 1: Final-Drill #19 the screw holes in the F-1050B Bolt Access Plate.

Step 2: Deburr the edges of the F-1050B Bolt Access Plate. Prime the plate if desired. See Figure 1 for installation of the bolt access plate.




FIGURE 1: BOLT ACCESS PLATE INSTALLATION