


VAN'S AIRCRAFT, INC.



NOTE: A stainless steel pitot tube with cover is available from the VAN'S ACCESSORIES CATALOG part number VENT P-100.

NOTE: The pitot installation is for the left wing only.

Step 1: Make the PITOT TUBE from ATO-032 X 1/4. Start with a piece of tubing at least 8 inches long, bend the tubing and then trim to match the dimensions shown in Figure 1. See Section 5P for more information on aluminum tubing. Do **not** flare the end yet!




Step 2: Enlarge the hole in the **bottom** aft row of rivets left open in Section 17 for the PITOT TUBE in the W-1001-L Leading Edge Skin and main spar assembly to 7/16 diameter.

Step 3: Install the bulkhead fitting and retaining nut onto the main spar and leading edge assembly (where the PITOT TUBE attaches), see Figure 2.

Step 4: Make the W-PITOT LINE Pitot Line from ATO-032 X 1/4. Start with a piece of tubing at least 92 1/2 inches long. Insert the pitot line through snap bushings installed in the forward tooling hole of the inboard wing ribs. Slide the nut and sleeve onto the inboard end of the pitot line as shown in the exploded view in Figure 2. Check that the last sentence has been completed, lest you flare the pitot line to soon. Flare the end of the pitot line. Attach the inboard bulkhead fitting to the pitot line as shown in Figure 2.

Step 5: Bend and trim the W-PITOT LINE Pitot Line to connect with the bulkhead fitting used to attach the PITOT TUBE. Insert the nut and sleeve onto the pitot line. Flare the end of the pitot line. Connect the pitot line to the outboard bulkhead fitting on the main spar assembly.

Step 6: Insert the nut and sleeve onto the long leg of the PITOT TUBE as shown in Figure 3. Flare the end of the long leg of the pitot tube. The pitot tube can be installed now, but since it can easily be damaged during storage of the wings it is safest to delay the installation until the final assembly of the aircraft.






FIGURE 2: INBOARD PITOT LINE INSTALLATION



Step 1: To prevent the WH-F1001 Wires from interfering or rubbing on the W-1017A Stick To Bellcrank Pushrod wrap the wire around the pitot tube along the entire length of the rib bay as shown in Figure 1. Cross over from the pitot tube to the main wiring run snap bushing and to the root end of the wing assembly.






FIGURE 1: ROUTING WIRES INTO THE MAIN WING WIRE RUN

Step 2: Attach a set of spade connectors to the end of both WH-F1001 Wires as shown in Figure 2.

Step 3: Reinstall the fuel tank to the wing per Section 18.





Note: The W-1028B Wing Box J-Stiffener - Short and W-1004-L Inboard Wing Skin has already been installed in the Quick Build kit. The remaining instructions in this section are for the left wing only, the right wing is a mirror of the left.

Step 1 (Quick Build): Fabricate the W-1028A Wing Box J-Stiffener -Long by cutting a piece of J-channel, 92 1/4 inches long. Draw a centerline on the flange as shown in Figure 1.

Draw a similar centerline on the portion of the W-1028B Wing Box J-Stiffener - Short that protrudes from beneath the installed W-1004-L Bottom Inboard Wing Skin.




FIGURE 1: J-STIFFENER DETAIL

Step 2: Place the wing top face down onto a padded surface. Insert the W-1028A Wing Box J-Stiffener - Long into the J-stiffener cutout in the wing ribs.

Step 3 (Standard Kit): Insert the W-1028B Wing Box J-Stiffener - Short into the J-stiffener cutout in the wing ribs. Cleco the W-1004-L Bottom Inboard Wing Skin to the main spar, rear spar, wing ribs and stiffener.

Step 3 (Quick Build Kit): Align the outboard edge of the W-1028A Wing Box J-Stiffener - Long with the web of the W-1012-R Outboard Wing Rib, then clamp the webs of both J-Stiffeners together where they overlap (Check that the rib is straight).

Step 4: Cleco the W-1005-L Bottom Outbd Wing Skin to the spars, ribs, stiffeners and bottom inbd wing skin (note the outboard skin overlaps the inboard skin)

Step 5 (Standard Kit): Final-Drill #40 all the common holes between the W-1004-L and W-1005-L Bottom Wing Skins and the W-1028A and W-1028B Wing Box J-Stiffeners.

Step 5 (Quick Build Kit): Align the line drawn on the W-1028A Wing Box J-Stiffener - Long with the center of the holes common to the line in the bottom wing skins.

Match-Drill #40 the bottom outbd wing skin to both the wing box stiffeners.


Step 6: Final-Drill #40 all the holes that are common to the bottom wing skins, spars and ribs of the wing. Final-Drill #19 the screw holes for the nutplates called out on Page 20-6. Figure 2, that will be installed along the inboard edge of the W-1004-L Bottom Inbd Wing Skin, Match-Drill #40 the attach holes for these nutplates into the W-1010-R Inboard Wing Rib using the bottom inbd wing skin as a drill guide.

Step 7: Disassemble the bottom skins and J-stiffeners from the wing assembly.

Step 8: Modify the lap joint between the W-1004-L and W-1005-L Bottom Wing Skins in a similar way as described on Page 16-2, Step 5.

Step 9: Deburr the edges and holes of all parts. Dimple the W-1004-L and W-1005-L Bottom Wing Skins, except the aft most hole common with the aft most inboard nutplate, see Figure 2. Dimple the W-1028A and W-1028B Wing Box J-Stiffeners. Dimple the main wing ribs. Prime all parts if/as desired.

Step 10 (Standard Kit): Lay the W-1028B Wing Box J-Stiffener - Short into the J-stiffener notch in the wing ribs. Cleco the W-1004-L Bottom Inbd Wing Skin to the bottom flange of the rear spar, to the aft half of the wing ribs, and to the wing box J-stiffener. Carefully, so as not to form a kink, pull the unclecoed forward portion of the skin back to gain access to the rear spar with a bucking bar. Rivet callouts are found on Page 20-6, Figure 2. Begin riveting at the rear spar in the center of the skin and work forward and outward toward toward corners. As the riveting proceeds forward, gain access for bucking the rivets through the larger lightening holes in the wing ribs and the access holes in the skin.



VAN'S AIRCRAFT, INC.

W-1012-R

RV-10 | PAGE 20-5

DATE: 07/24/14 REVISION: 1

