Heat Engine

QC < 0 wasted heat leaves the system

Cold resevoir with temperature To

QC W = ngine does work to the surroundinge

QH > 0 New is put into the system

Hot resevoir with temperature TH

Refrigerators

QC > 0 Heat is removed from the cold region and enter the system

Cold resevoir with temperature To

