# Generic universal I/O Controller for USB



**Code Mercenaries** 

#### 1.0 Features

- USB interface
- USB V1.1/2.0 compliant low speed device
- USB HID 1.1 compliant
- 32 general purpose I/O pins on IOW40 16 general purpose I/O pins on IOW24
- Supports IIC compatible devices
- Supports HD44780 compatible display modules and several graphic display modules
- Supports SPI slave devices up to 2MBit/sec (IOW24)
- Supports receiving RC5 IR remote control data (IOW24)
- Drives LED matrix up to 8x32 with few external shift registers
- Supports 8x8 or 16x8 switch or key matrix (IOW40)
- Two 24 bit capture timers with  $4\mu$ sec resolution (IOW24)
- Easy to use starter kit
- Software support for Mac, Linux, and Windows
- No USB knowledge necessary to use
- Single +5V power supply
- Available SSOP48 package and DIL40 module (replacing PDIP40 package), or DIL24 and SOIC24.

#### 1.1 Variants

IO-Warrior is available in several variants. The IOW24PowerVampire and the IO-Warrior56 are covered by separate data sheets.

Custom modifications are possible.

### **IO-Warrior24**

- 16 general purpose I/O pins, typ. 125Hz read
- IIC master, typ. 750 bytes/sec throughput
- Alphanumeric and graphic display support
- RC5 IR remote control receiver
- Hardware SPI master interface up to 2Mbit/sec bitrate, typ. 750 bytes/sec throughput
- LED matrix with up to 8x32 LEDs with the support of external register/drivers
- Two 24 bit capture timers with  $4\mu$ sec resolution
- Minimal external component count
- Identifies as either low power (100mA) or high power (500mA) bus powered device. Pin selectable
- Easy to use starter kit for immediate access
- DIL24 or SOIC24 package

#### IO-Warrior40

- 32 general purpose I/O pins, typ. 125Hz read
- IIC master, typ. 750 bytes/sec throughput
- Alphanumeric and graphic display support
- LED matrix with up to 8x32 LEDs with the support of external register/drivers
- 8x8 or 16x8 switch or key matrix
- Minimal external component count
- Identifies as either low power (100mA) or high power (500mA) bus powered device. Pin selectable
- Easy to use starter kit for immediate access.
- SSOP48 package or DIL40 module (replacing PDIP40 package)

#### 1.2 Custom variants

Custom adaptions are available on request. If necessary complex functions can be added to the standard chips to directly control specific circuits.

#### 2.0 Functional overview

IO-Warrior offers a simple access to the USB. Many projects that formerly used the parallel port or some other kind of direct I/O interface today face the problem that getting simple things to work on the USB is quite complex.

With a serial or parallel port you needed only a simple circuit to control an external relay or read a single switch. With USB you need a microcontroller that handles all the protocol work to do the same thing. Several standard commands need to be supported to get a device accepted as a USB device, let alone implementing any real function.

IO-Warrior brings simplicity to the USB. The protocol is encapsulated in the IO-Warrior Chip. You only have to care about the 16 or 32 I/O pins and have to write only a few simple lines of code to access them.

IO-Warrior also supports a range of industrial standard interfaces to simplify interfacing to certain chips or modules. These interfaces are handled internally in IO-Warrior removing the bandwith wasting controlling of individual pins.

Content	
1.0 Features	1
1.1 Variants	1
1.2 Custom variants	1
2.0 Functional overview	1
2.1 Product selection matrix	3 5 8 8 9
3.0 Pin Configurations	5
4.0 Pin Descriptions IO-Warrior40	8
4.1 Pin Descriptions IO-Warrior24	8
4.2 Pin descriptions	
4.3 Special mode pin functions	9
4.3.1 IIC Mode pins	10
4.3.2 LCD Mode pins	10
4.3.3 SPI Mode Pins (IOW24 only)	10
4.3.4 RC5 Mode Pins (IOW24 only)	10
4.3.5 LED Matrix Mode Pins	11
4.3.6 Switch Matrix Mode Pins (IOW40 only)	11
4.3.7 Capture Timer Mode Pins (IOW24 only)	11
5.0 Device Operation	12
5.1 Accessing IO-Warrior	12
5.2 IO-Warrior communication	12
5.3 IO-Warrior input behaviour	12
5.5 IO-Warrior output behaviour	12
5.6 Using pins as inputs or outputs	12
5.7 Power supply	13
5.8 Suspend	13
5.9 Remote Wakeup	13
5.10 Special mode I/O	14
5.10.1 IIC Special mode function	14
5.10.2 LCD Special mode function	16
5.10.3 SPI Special mode function (IOW24 only)	17
5.10.4 Getting current pin status	18
5.10.5 Receiving RC5 IR codes (IOW24 only)	18
5.10.6 Driving LED matrix	18
5.10.7 Switch Matrix Mode (IOW40 only)	19
5.10.8 Capture Timers (IOW24 $\geq$ V1.0.3.0 only)	20
7.1 Packaging info	24
7.2 USB VendorID and ProductID	24
7.3 Serial numbers	24
7.4 Currently shipping versions	24
8.2 Warning about USB cables	27
8.3 Jumpers on the IOW40 Starter Kit	27
8.3.1 Jumpers on the IOW24 Starter Kit	27
8.4 Adding custom circuits	27
8.5 Example circuits	27
8.5.1 Drivers	27
8.5.2 Isolating inputs	28
8.5.3 Protecting inputs and outputs	28
8.5.4 Using the LCD function	28 30
9.0 Package Dimensions	32
10.0 ESD Considerations	32 32
10.1 EMC Considerations	33
11.0 Revision History 12.0 Legal Stuff	33 34
12.0 Logai Stati	JT

#### 2.1 Product selection matrix

Type	I/O Pins	LCD	IIC	SPI	RC5 IR	Keys	LEDs	Timer	DIL40	SSOP48	DIL24	SOIC24	Starter Kit
IO-Warrior40	32	√				√				$\sqrt{}$			
IO-Warrior24	16	√		√	√			√			√	√	√
IO-Warrior24PV	12			√							√	√	
IO-Warrior56	50	√		√		√							√


### 2.2 Starter Kits

With the IO-Warrior Starter Kits you can make your first steps with IO-Warrior40 or IO-Warrior24 easily. A couple elements on the kit allow first experiments with inputs and outputs, the bread board area provides space to test your individual circuit. There are separate starter kits for IOW40 and IOW24. The starter kits are sold unassembled. A couple minutes soldering will provide you with a working unit.

#### 2.2.1The IO-Warrior40 Starter Kit

The IOW40KIT for IO-Warrior40 provides eight LEDs and a button that can be used for first experiements. The starter kit is sold unassembled.

Assembled the starter kit for IO-Warrior40 looks similar to this:




Actual components supplied with the kit may vary from those shown here.

### 2.2.2 The IO-Warrior24 Starter Kit

The IOW24KIT for IO-Warrior24 provides a LED, an IR receiver, and the circuit and connector to directly connect a LCD module.

The starter kit is sold unassembled.


Assembled the starter kit for IO-Warrior24 looks similar to this:



Actual components supplied with the kit may vary from those shown here.


# 3.0 Pin Configurations

### IO-Warrior40-MOD DIL40 Module




All drawings: TOP VIEW!

### IO-Warrior 40-S SSOP48



All drawings: TOP VIEW!

## IO-Warrior 24-P/-S DIL24 / SOIC24



All drawings: TOP VIEW!

# 4.0 Pin Descriptions IO-Warrior40

Name	I/O	Туре	Pins (DIL40)	Description
D+, D-	I/O	special	1, 2	USB differential data lines
P0.0, P0.1,	I/O	I/O open drain, internal	23, 18, 24, 17, 25, 16,	First I/O Port. P0.0 is used at power on to select low
P0.2, P0.3,		pullup	26, 15	or high power mode
P0.4, P0.5,				
P0.6, P0.7				
P1.0, P1.1,	I/O	I/O open drain, internal	27, 14, 28, 13, 29, 12,	Second I/O Port
P1.2, P1.3,		pullup	30, 11	
P1.4, P1.5,				
P1.6, P1.7				
P2.0, P2.1,	I/O	I/O open drain, internal	31, 10, 32, 9, 33, 8,	Third I/O Port.
P2.2, P2.3,		pullup	34, 7	
P2.4, P2.5,				
P2.6, P2.7				
P3.0, P3.1,	I/O	I/O open drain, internal	35, 6, 36, 5, 37, 4, 38,	Fourth I/O Port. P3.7 must be pulled high with a
P3.2, P3.3,		pullup	3	$100$ k $\Omega$ resistor for proper operation of the chip.
P3.4, P3.5,				Strong drive outputs, capable of driving LEDs
P3.6, P3.7				direct.
PullToGND	I		19	Used during manufacturing, connect to GND
GND		Power supply	20, 39	Ground
Vcc		Power supply	40	Supply voltage
XOut	О		22	On chip oscillator output
XIn	I		21	On chip oscillator input

# 4.1 Pin Descriptions IO-Warrior24

Name	I/O	Type	Pins	Description
D+, D-	I/O	special	16, 15	USB differential data lines
P0.0, P0.1,	I/O	I/O open drain, internal	1, 2, 3, 4, 24, 23, 22,	First I/O Port.
P0.2, P0.3,		pullup	21	
P0.4, P0.5,				
P0.6, P0.7				
P1.0, P1.1,	I/O	I/O open drain, internal	5, 20, 6, 19, 7, 18, 8,	Second I/O Port
P1.2, P1.3,		pullup	17	
P1.4, P1.5,				
P1.6, P1.7				
Power	I	Input internal pull	12	Used to set high or low power mode
		down		
PullToGND	I		10	Used during manufacturing, connect to GND
GND		Power supply	9	Ground
Vcc		Power supply	14	Supply voltage
Vreg	0	Regulated 3V out	11	Power for D- pullup resistor
NC			13	do not connect

# 4.2 Pin descriptions

#### D+, D-

Differential data lines of USB. Connect these signals direct to a USB cable. D- requires a pull up resistor, see application circuit for details.

For a PCB layout make sure to run these two signals next to each other. USB data is a differential signal that produces best signal quality and lowest RF emission if the two lines are close to each other.

#### P0.0..P0.7

First I/O port of the chip. These pins correspond with the lowest 8 bits of the input or output (bits 0..7).

On IOW40 P0.0 serves the double purpose of determining the power mode of the chip. To set the desired power mode P0.0 must be pulled high or low using a  $100k\Omega$  resistor (or less). IO-Warrior40 reads the status on this pin after a reset prior to enabling the internal pull up resistor.

A high on P0.0 on reset sets the high power mode, this means the IO-Warrior40 will report as a high power, bus powered device drawing up to 500mA. Pulling P0.0 low on reset sets the low power mode specifying 100mA maximum power draw.

#### P1.0..P1.7

Second I/O Port. Corresponds to the bits 8..15.

#### P2.0..P2.7 (IOW40 only)

Third I/O Port. Corresponds to the bits 16..23.

### P3.0..P3.7 (IOW40 only)

Fourth I/O Port. Corresponds to the bits 24..31. P3.7 does need to be pulled high with a  $100k\Omega$  resistor on power up. This is necessary for proper function of the chip.

P3.0..P3.7 have sufficient current sinking capability to directly drive LEDs.

#### **Pull to GND**

This pin is used during production of the IO-Warrior chips, connect to GND.

### XOut, XIn (IOW40 only)

Connection for external oscillator. A 6MHz ceramic resonator should be connected here, no additional components necessary.

Using a crystal results in unstable operation as the oscillator is optimized for use with ceramic resonators.

An external 6MHz clock may be connected to XIn, XOut has to be left floating in this case.

#### **GND**

Power supply ground.

#### Vcc

Supply voltage.

A 100nF ceramic capacitor is required to be connected directly to the power supply pins. The two ground pins of IO-Warrior have to be connected in the shortest possible way, no other considerations may have any precedence over this.

### Vreg (IOW24 only)

Regulated 3V output, to be used only for the purpose of powering the USB D- pull up resistor. Do not use this pin as a supply for any other circuit than the pull up resistor.

### Power (IOW24 only)

Input to set the power mode. The status of the pin is checked only at power up and bus reset. Pulling this pin to high sets high power mode, this means the IO-Warrior24 will report as a high power, bus powered device drawing up to 500mA. Pulling Power low on reset sets the low power mode specifying 100mA maximum power draw.

### 4.3 Special mode pin functions

IO-Warrior supports driving IIC compatible chips and HD44780 compatible display modules and some other display modules direct. IO-Warrior24 does also have a SPI interface. Handling IIC via the normal generic I/O would be very slow as each edge of data and clock would have to be transmitted separately. At a rate of 125 such transactions per second (which is about the maximum IO-Warrior is allowed by USB specifications) the maximum bit rate would be around 30 bits/sec.

To make IIC and other devices usable IO-Warrior implements the special mode functions. By handling the IIC inside IO-Warrior the actual data rate is increased to about 6000 bits/sec or 750 bytes/sec.

When any of the special mode functions is activated a couple pins will no longer respond as generic I/O pins but are under control of the activated special mode function.

### 4.3.1 IIC Mode pins

IO-Warrior can act as an IIC master with about 100kbit/sec data rate (actual throughput is about 750bytes/sec). Multi-Master mode is not supported by IO-Warrior, it has to be the only master on the IIC

Since the IIC bus in IO-Warrior is software driven it does not have as stable a clock timing as hardware IIC masters have. Make sure that the devices you drive with IO-Warrior don't have a problem with some clock jitter.

The following pins get reassigned when the IIC function is enabled:

Function	IOW24	IOW40
SCL	P0.1	P0.6
SDA	P0.2	P0.7

These pins will no longer be affected by the data sent via the normal port setting command. Both pins have internal pull up resistors and can be connected direct to IIC compatible chips.

On IOW24 simultaneous use of the IIC function and capture timer B is not possible.

### 4.3.2 LCD Mode pins

IO-Warrior has support for controlling alphanumeric display modules based on or compatible with HD44780 as well as some graphic displays.

Attention: IOW24 can use either LCD or SPI but never both at the same time.

IOW40 can use either 16x8 key matrix mode or LCD, never both at the same time.

LCD mode and LED matrix mode can not be used at the same time on IOW24 and IOW40.

The following pins get reassigned when the LCD function is enabled:

Function	IOW24	IOW40
/On	P0.4	P0.2
RS	P0.5	P0.3
R/W	P0.6	P0.4
Е	P0.7	P0.5
Data0	P1.0	P1.0
Data1	P1.1	P1.1
Data2	P1.2	P1.2
Data3	P1.3	P1.3
Data4	P1.4	P1.4
Data5	P1.5	P1.5
Data6	P1.6	P1.6
Data7	P1.7	P1.7

When the LCD function is enabled these pins will no longer be affected by the normal port setting command.

/On should be used to enable power supply to LCD modules that have high current demand or backlighting. The /On signal is low when the LCD function is enabled, it does go high when IO-Warrior enters suspend mode or when the LCD function is disabled.

### 4.3.3 SPI Mode Pins (IOW24 only)

IO-Warrior24 supports a hardware SPI master interface. This means it can talk to SPI slave devices with a data clock speed of up to 2MHz. Actual data throughput is significantly lower since USB allows only 100 reports per second to be send to low speed devices (actual system implementations allow 125 reports per second)

The following pins get reassigned when the SPI function is enabled:

Function	IOW24	IOW40
/DRDY	P0.3	-
/SS	P0.4	-
MOSI	P0.5	-
MISO	P0.6	-
SCK	P0.7	-

When the SPI function is enabled these pins will no longer be affected by the normal port setting command.

SPI and LCD can not be used at the same time since these functions share some pins.

#### 4.3.4 RC5 Mode Pins (IOW24 only)

IO-Warrior24 supports receiving IR remote control commands according to the RC5 code.

For this function it is necessary to connect an appropriate IR receiver module like the Vishay TSOP1736.

The following pins get reassigned when the RC5 function is enabled:

Function	IOW24	IOW40
RxD	P0.0	-

When the RC5 function is enabled these pins will no longer be affected by the normal port setting command.

RC5 mode can not be used at the same time as any of the capture timers.

### 4.3.5 LED Matrix Mode Pins

IO-Warrior supports driving a LED matrix with up to 8x32 LEDs. The LED matrix mode can not be used at the same time as the LCD mode. IOW40 can use either 16x8 key matrix mode or LED matrix mode, never both at the same time.

Function	IOW24	IOW40
/OE	P1.0	P1.0
Strb	P1.1	P1.1
Clk	P1.2	P1.2
Data	P1.3	P1.3

When the LED Matrix function is enabled these pins will no longer be affected by the normal port setting command.

/OE is driven high when IO-Warrior enters the suspend mode. The external driver should then disable to stay within the USB power limits for suspend mode.

For more details on how to control a LED matrix please refer to the separate application note.

## **4.3.6 Switch Matrix Mode Pins (IOW40 only)**

IO-Warrior40 supports scanning of a 8x8 or 16x8 matrix of keys or switches. When this function is enabled P3.0..7 will turn off their internal pull up resistors and will be used as the Y lines that are periodically driven to Gnd voltage level. P2.0..7 will serve as the X0..7 matrix inputs, they will keep their internal pull up resistors active so a closed switch in the matrix will pull down the X line when the corresponding Y line is driven low. If the 16x8 mode is enabled P1.0..7 will be used as

additional X lines, serving as X8..15. The 16x8 matrix mode can be used only if the LCD and LED matrix functions are not in use.

To allow more than two switches to be closed at the same time and still be able to faultlessly detect which of the matrix points are closed it is necessary to insert a diode in series with every key or switch in the matrix. The kathodes of the diodes have to be connected to the Y lines (P3.0..7).

The following pins get reassigned when the key mode is enabled:

Function	IOW24	IOW40
X0	-	P2.0
X1	-	P2.1
X2	-	P2.2
X3	-	P2.3
X4	-	P2.4
X5	-	P2.5
X6	-	P2.6
X7		P2.7
X8	-	P1.0
X9	-	P1.1
X10	-	P1.2
X11	-	P1.3
X12	-	P1.4
X13	-	P1.5
X14	-	P1.6
X15	-	P1.7
Y0	-	P3.0
Y1		P3.1
Y2	-	P3.2
Y3	-	P3.3
Y4	-	P3.4
Y5	-	P3.5
Y6	-	P3.7
Y7	_	P3.7

When IO-Warrior40 enters the suspend mode the X and Y lines will be pulled high by internal pull up resistors. Closing a switch/key does not wake the IO-Warrior.

### 4.3.7 Capture Timer Mode Pins (IOW24 only)

IO-Warrior24 has two capture timers that can measure falling and rising edges with a resolution of  $4\mu$ sec. When this function is turned on P0.0 and/or P0.1 will be used for the timers and be no longer available for standard I/O. P0.0 is shared between the RC5 receiver and capture timer A. P0.1 is shared between the IIC function and capture timer B. The RC5 receiver and the capture timers can not be used at the same time since they share internal resources on the chip.

Function	IOW24	IOW40
Capture A	P0.0	-
Capture B	P0.1	-

### 5.0 Device Operation

Due to the fact that all current operating systems offer an especially easy access to devices in the HID class, IO-Warrior was designed as a generic HID device. While this does not exactly fit the device it makes using it a lot easier.

By identifying as a generic HID class device IO-Warrior avoids being controlled by any of the higher level system drivers, which makes it possible to access IO-Warrior from application level.

### **5.1 Accessing IO-Warrior**

A common misconception with people new to the USB is that they think they can "talk to the USB port". The truth is that you do that as likely as you are going to directly talk to your Ethernet port or PCI bus.

Communication on the USB is always with a specific device attached to the USB. The USB itself is only the medium through which you communicate.

To get access to a certain device you have to look for the VendorID and ProductID of that device. The specific mechanisms for doing so depend on the individual operating system.

For details refer to our sample code.

#### 5.2 IO-Warrior communication

IO-Warrior has three USB endpoints. Endpoints are like virtual communication ports into or out of the device.

An endpoint can be assigned to an interface. Interfaces are like virtual devices or subsystems within a device. IO-Warrior uses interface 0 to talk to the pins directly and interface 1 to talk to the special mode functions.

Endpoint 0 is a standard endpoint that is present on all USB devices. It does use the control transfer mode and is used by the system to get information about the device and to configure the device.

Endpoint zero can also be used to send data to the devices functions. IO-Warrior is using endpoint zero for the output data and to send commands to the special mode functions.

A SetReport request sending a four byte output report (two bytes for IOW24) to interface 0 sets the port pins. SetReport requests to interface 1 with a length of 8 bytes are used to control the special mode functions.

For input data IO-Warrior is using endpoint 1 as an interrupt-in endpoint. Interrupt in this case is a bit misleading. For USB interrupt means that data is sent when there is new data available, the host computer is periodically asking the device for new

data, the device itself can not initiate the data transfer. IO-Warrior sends a new report any time it detects a change to the input pin status.

Reactions to commands to the special mode functions are sent via endpoint 2, also in interrupt transfer mode.

### 5.3 IO-Warrior input behaviour

IO-Warrior scans the status of all pins once every millisecond. If it detects a change from the last status a new report via endpoint 1 is issued. Pins which are currently used by a special mode function are not checked.

Some care must be taken to not input signals with frequencies too high for IO-Warrior to handle properly.

Should the signal return to its former status before the new report is send off this report gets overwritten by the next one indicating the original status. So it will look like nothing happened.

Due to the protocol specifics of USB it is only possible to send one report every 10msec. Though most OSes implement their USB in a way that results in one report every 8msec.

### **5.5 IO-Warrior output behaviour**

Upon receiving a SetReport request IO-Warrior writes the new data to the output pins in groups of eight pins each. Pins 0.0 to 0.7 get the new data first, then 1.0 to 1.7, 2.0 to 2.7, and last 3.0 to 3.7. The time between the individual output chunks is about  $1.5\mu$ sec.

#### 5.6 Using pins as inputs or outputs

All I/O pins on IO-Warrior can be used as input or output pins.

Basically all pins act as inputs all of the time. When receiving an input report from IO-Warrior you always get the current status on the pins.

Writing a 0 as output value to any pin causes it to drive the pin low with an open drain driver. Usually this will result in this pin being read as a zero input as well, unless so much current has to be drained by the pin that the voltage at it gets above the threshold level (you will see this when driving the LEDs on the starter kit).

Writing a 1 to a pin causes the open drain driver to be turned off. The pin will be pulled high by an internal pull up resistor. Now the pin acts either as an output with a high level, or can be used as an input.

### **5.7 Power supply**

USB does allow a device to be "Bus Powered". This means the device does get its power off the USB port. To avoid overloading on the USB ports devices need to advertise their power requirements. There are two power classes for devices: Low power and high power. Low power devices may draw up to 100mA off the USB, high power devices up to 500mA.

Likewise there are high power and low power ports. Usually high power ports are those on the motherboard and on hubs with external power supply or hubs in a monitor. Low power ports are typically on hubs that get their power off the USB, like hubs in keyboards.

If the system decides that there is not sufficient power to supply a high power decive that device does not get enabled.

IO-Warrior can operate either as a high power or low power device. Pulling the P0.0 pin on IOW40 or the Power pin on IOW24 high or low at reset sets the desired power rating.

This allows to configure IO-Warrior optimally for supporting external circuits.

#### 5.8 Suspend

All devices on the USB port need to support the suspended state. When the host computer stops to periodically access the USB, like when it goes to sleep, all devices need to enter the suspended state and drop their power draw to less than  $500\mu A$  for low power devices or less than 2.5 mA for high power devices.

When entering suspended state IO-Warrior pulls all pins high. Care must be taken in designing external circuits so that they will draw no more than the allowed suspend power rating while all pins of IO-Warrior are high.

#### **5.9 Remote Wakeup**

IO-Warrior chips support the remote wakeup feature. They are able to wake the host computer from sleep state if the host operating system has enabled this feature.

Remote wakeup is initiated by IO-Warrior if any pin is pulled low while the chip is in suspended state.

### 5.10 Special mode I/O

To enable IO-Warrior to talk to devices that have more complex demands we have added the special mode functions. When any of these functions is enabled a couple pins of IO-Warrior turn into special function pins.

Talking to the special mode functions is handeled via the USB interface 1, which is also configured as generic HID compliant.

Commands to the functions are sent via endpoint 0 as SetReport requests to interface 1. Replies from the functions are returned as interrupt in reports via endpoint 2.

To talk to these functions and to handle different requests to them ReportIDs are used which enable multiple functions to use the same endpoint. All reports to and from special mode interfaces are always eight bytes long, including the ReportID.

The following chapters describe the individual special mode functions.

## 5.10.1 IIC Special mode function

The IIC function is enabled and disabled by sending a report with the following structure with ReportID=1 to interface 1:

ReportID	1	2	3	4	5	6	7
\$01 out		flags	timeout	\$00	\$00	\$00	\$00

enable=\$01 enables the IIC function, \$00 disables it. Other values are reserved for future use.

Upon enabling IIC the SDA and SCL pins are pulled high and are no longer under control of SetReport requests to interface 0. Disabling IIC does return the pins under control of interface 0 and pulls them high initially.

flags is used to deactivate the internal pull up resistors for SDA and SCL (only on IOW24) and/or select the use of the Sensirion protocol:

- 7 Disable Pull Ups (1 = disable) IOW24 only
- 6 Use Sensibus Protocol (1 = enable)
- 5 unused, write zero
- 4 unused, write zero
- 3 unused, write zero
- 2 unused, write zero
- 1 unused, write zero
- 0 unused, write zero

Bit 7 - "Disable Pull Up" is available only on IOW24. When this bit is set the internal pull up resistors of the IIC pins are disabled. The status of the pull up resistors can not be changed while the IIC function is active. Disabling and again enabling the IIC function is necessary to change the status of the pull-up resistors.

Bit 6 - "Use Sensibus Protocol" selects the use of the Sensirion protocol variant if set. The only difference is that the start and stop conditions are handeled according to the Sensirion protocol and a handshake on read is added. The Sensibus protocol can be activated and deactivated while the IIC functions is active by sending another enable command with this bit set differently.

The timeout byte sets the maximum time IOW waits for SCL to be released by the slave when clock stretching handshake is used. Time is timeout x  $500\mu$ sec, writing a zero sets timeout to  $256\times500\mu$ sec.

If the timeout expires due to the slave pulling down SCL too long, IO-Warrior will return an error, just like when the slave generates no Ack signal.

A write request to the IIC is send with ReportID=2 and has the following format:

ReportID	1	2	3	4	5	6	7
\$02 out	flags	data	data	data	data	data	data

flags contains the following bits:

- 7 Generate Start
- 6 Generate Stop
- 5 unused, write zero
- 4 unused, write zero
- 3 unused, write zero
- 2 data count MSB
- 1 data count
- 0 data count LSB

If bit 7 - "Generate Start" is set a start signal (SDA falling edge while SCL is high) is generated on the IIC prior to sending out the first data byte.

Bit 6 - "Generate Stop" causes a stop signal (SDA goes high while SCL is high) to be generated after sending the last valid data byte of this report.

"data count" gives the number of valid data bytes in the report. The number may range from zero to six, higher values cause the report to be ignored.

To do write transactions that are longer than six bytes, send the first report with just the "Generate Start" bit set, then send additional reports with neither bit 6 or 7 set until the report with the last bytes is send which has the "Generate Stop" bit set.

Any write transactions are acknowledged by a report via interrupt-in endpoint 2:

ReportID	1	2	3	4	5	6	7
\$02 in	flags	\$00	\$00	\$00	\$00	\$00	\$00

flags contains the following bits:

- 7 Error bit, 1=error
- 6 unused, zero
- 5 unused, zero
- 4 unused, zero
- 3 unused, zero
- 2 data count MSB
- 1 data count
- 0 data count LSB

"data count" indicates the last byte that was successfully transfered and acknowledged by the slave (if any). An error is indicated when the slave does not acknowledge a transfer.

Reading data off the IIC is initiated with a ReportID=3. The initiating report has the following format:

ReportID		2	3	4	5	6	7
\$03 out	count	command	\$00	\$00	\$00	\$00	\$00

"command" holds the command byte to be send to the IIC. "count" is the number of bytes that should be read off the IIC after sending the command byte, values 1 to 255 are valid.

A start signal is automatically generated before

sending the command byte and a stop is generated after the last data byte is received.

Data is returned in input reports with ID=3 (which is different from the output ReportID=3 used to initiate the read transaction) via endpoint 2. The data is returned in chunks of up to six bytes each with an error flag and byte count. Multiple reports may be returned in reaction to a read request:

ReportID	1	2	3	4	5	6	7
\$03 in	flags	data	data	data	data	data	data

flags contains the following bits:

- 7 error, set if slave does not ack command byte
- 6 unused, zero
- 5 unused, zero
- 4 unused, zero
- 3 unused, zero
- 2 data count MSB
- 1 data count
- 0 data count LSB

Should the IIC slave fail to acknowledge the command byte the error flag will be set and the transaction aborted. IIC does not have an error condition during the actual reading of data after the command byte was sent.

Clock stretching handshake, timeout, Sensibus option and disabling pull-up resistors have been added with chip revision V1.0.3.0 and are not available with older chips.

### 5.10.2 LCD Special mode function

The LCD special mode function supports display modules that are compatible with the HD44780 controller and several graphic display controllers that use a compatible interface. This controller is made by Hitachi and has set the de-facto standard for alphanumeric LCD modules.

The modules come in various configurations with up to 80 characters total in any kind of arrangement from single line to four lines. Displays with more than 80 characters typically use more than one HD44780. IO-Warrior does not directly support modules with more than a single HD44780, some additional hardware is required for this

It is recommended to read the HD44780 manual for using the LCD function. Also have a look at our application note AN5: Driving Display Modules with IO-Warrior.

The LCD function is enabled by sending an output report with ID 4 to the USB interface 1:

ReportID	1	2	3	4	5	6	7
\$04 out	enable	\$00	\$00	\$00	\$00	\$00	\$00

enable = \$00 disables the LCD function. enable = \$01 enables the LCD function, other values are reserved.

Upon enabling the LCD function the Pins are put under control of the LCD function and can no longer be controlled by SetReport to interface 0.

The /On pin is pulled low when the LCD function is enabled, it will go high when the IO-Warrior enters suspend state.

IOW24 does not allow to use SPI and LCD at the same time. If SPI is enabled at the time a command to enable LCD is received the command is ignored. This means none of the LCD commands will be executed when received nor will they send any response. IOW24 will acknowledge that it received the report with the command but not execute the corresponding function and not send any reports in reaction to the command.

To write data to the connected LCD module an output report with ReportID 5 is written with the following format:

ReportID	1	2	3	4	5	6	7
\$05 out	flags	data	data	data	data	data	data

"flags" contains the following bits:

- 7 RS, Register Select bit
- 6 unused, zero
- 5 unused, zero
- 4 unused, zero
- 3 unused, zero
- 2 data count MSB
- 1 data count
- 0 data count LSB

The status of the RS bit is used to set the RS line to the LCD module. This allows access to the Instruction register (RS=0) or Data Register (RS=1) of the LCD module.

With "data count" the number of bytes to be written is specified. IO-Warrior will write up to six data bytes to the register specified by the RS bit. The Busy bit of the LCD module is automatically checked and data written only when the LCD module is ready to accept it.

To read data from the LCD module an output report with ID 6 is sent to interface 1:

ReportID	1	2	3	4	5	6	7
\$06 out	flags	\$00	\$00	\$00	\$00	\$00	\$00

"flags" contains the following bits:

- 7 RS, Register Select bit
- 6 unused, zero
- 5 data count MSB
- 4 data count
- 3 data count
- 2 data count
- 1 data count
- 0 data count LSB

RS specifies which register is to be accessed. Data count sets the number of bytes to be read off the LCD (will be ignored if RS=0, only a single read will be done then).

Up to 63 bytes can be read with one request. The data read from the LCD module is returned in input reports with ID 6:

ReportID	1	2	3	4	5	6	7
\$06 in	count	data	data	data	data	data	data

"count" specifies the number of bytes returned in this report. If more than 6 bytes are requested the data will be returned in multiple reports.

With chip revision 1.0.3.0 a 16ms timeout for the Busy bit of the LCD has been added.

**5.10.3 SPI Special mode function (IOW24 only)** IO-Warrior24 has a hardware SPI interface enabling it to talk to many peripheral devices. IOW24 supports SPI master mode.

To enable the SPI function a report with ID 8 is sent to interface1:

1	$\sim$	2	1	- 5	6	7
1		J	4	J	U	/
mabla	mada	$\Phi \cap \cap$	$\Phi \cap \cap$	$\Phi \cap \cap$	$\Phi \cap \cap$	$\Phi \cap \cap$
nabie	mode	ΦUU	ΦUU	Φυυ	Φυυ	DOU!
	1 nable	1 2 nable mode	1 2 3 nable mode \$00	1 2 3 4 nable mode \$00 \$00	1 2 3 4 5 nable mode \$00 \$00 \$00	1 2 3 4 5 6 nable mode \$00 \$00 \$00 \$00

enable = \$00 disables the SPI and \$01 enables it. "mode" contains flags specifying the operating mode for the SPI:

- 7 unused, write zero
- 6 unused, write zero
- 5 unused, write zero
- 4 unused, write zero
- 3 CPOL
- 2 CPHA
- 1 data rate MSB
- 0 data rate LSB

The data rate select bits set the clock speed at which IO-Warrior is driving SCK:

- 00 2MBit/sec
- 01 1MBit/sec
- 10 0.5MBit/sec
- 11 0.0625MBit/sec

CPHA works together with CPOL to specify which clock edges are used to drive and sample data bits. CPOL = 0 causes SCK to idle low between data bytes, CPOL = 1 makes SCK idle high.

CPHA = 0 causes data to be driven on the first clock edge and sampled on the second edge. CPHA = 1 causes data to be driven on the second edge (first bit gets driven before the first edge) and sampled on the first edge.

Enabling SPI takes P0.3..P0.7 out of the control of interface zero.

SPI does always shift data in and out simultaneously. So there is only one command to send data out of SPI that does also result in the same number of bytes being read in and returned to the host. if the intention is to only read data from an external device it is still necessary to shift out the same number of dummy bytes to that device.

IOW24 does not allow to use SPI and LCD at the same time. If LCD is enabled at the time a command to enable SPI is received the command is ignored. This means none of the SPI commands will be executed when received nor will they send any response. IOW24 will acknowledge that it

received the report with the command but not execute the corresponding function and not send any reports in reaction to the command.

Data transfers on the SPI are initiated by a report with ID 9:

ReportID	1	2	3	4	5	6	7
\$09 out	flags	data	data	data	data	data	data

"flags" contains the following bits:

- 7 useDRDY, 1 = do handshake
- 6 SSactive, 1 = /SS stays active
- 5 ignoreDRDY, 1 = first byte ignores /DRDY
- 4 unused, zero
- 3 unused, zero
- 2 data count MSB
- 1 data count
- 0 data count LSB

"useDRDY" allows to enable a handshaking signal that allows the slave to signal if and when it is ready to accept or send data.

If "useDRDY" is = 1 IO-Warrior will check for the /DRDY signal to be low before it starts shifting a data byte. If the slave wants to pause the data transmission it has to pull /DRDY high before the end of the current byte transfer.

Upon starting a data transfer it may be desired to send the first byte without the slave signalling / DRDY low. By setting "ignoreDRDY" to 1 the first byte of this report is sent to the slave without checking /DRDY. Prior to shifting the next byte IO-Warrior will check the status of /DRDY.

"data count" has the number of bytes to shift, only values 1-6 are valid, others will be ignored.

IO-Warrior assertes /SS before starting to shift the first data byte of this report and will deassert it after completing the last byte, unless bit 6 "SSactive" is = 1. If "SSactive" is set /SS will stay asserted after the last byte of the report has been transfered, allowing more than 6 bytes to take part of a single transfer.

Data shifted in by IO-Warrior during a transaction is returned in a report with ID 9:

		1					
ReportID	1	2	3	4	5	6	7
\$09 in	count	data	data	data	data	data	data

"count" holds the number of valid bytes in the report.

### 5.10.4 Getting current pin status

Due to the way Windows implements HID support IO-Warrior is unable to continuously send its status. HID class devices do have a function that allows the host to set the rate at which reports should be repeated if there is no change to the data. Windows does this rate to zero for IO-Warrior, which means IO-Warrior may send data only if there are changes.

To be able to get the current status from IO-Warrior it does support a Special Mode Function that always returns the current status of all pins.

To get the port status just send a report with ID \$FF to interface 1:

ReportID	_	2	3	4	5	6	7
\$FF out	\$00	\$00	\$00	\$00	\$00	\$00	\$00

This will result in the current pin status to be returned immediately in an input report with ID \$FF with the following format:

ReportID		2	3	4	5	6	7
\$FF in	Port0	Port1	Port2	Port3	\$00	\$00	\$00

IOW24 will always return \$00 for Port2 and Port3.

#### 5.10.5 Receiving RC5 IR codes (IOW24 only)

IO-Warrior 24 has the capability to use a simple IR receiver module to receive IR remote control codes according to the RC5 format.

To enable the receiver function a report with ID \$0C is sent to interface 1:

ReportID	1	2	3	4	5	6	7
\$0C out	enable	\$00	\$00	\$00	\$00	\$00	\$00

enable = \$01 enables the RC5 function, enable = \$00 disables it again.

Any time IO-Warrior receives a valid RC5 command it does return the received data in an input report with ID = \$0C:

ReportID	-	2	3	4	5	6	7
\$0C in	data	addr	\$00	\$00	\$00	\$00	\$00

data contains the six bits of the command, addr contains the five address bits as well as the start bit (always 1), /C6 command bit and toggle bit.

### **5.10.6 Driving LED matrix**

IO-Warrior has the capability to drive a LED matrix of up to 8x32 with the aid of a few simple external driver chips.

To enable the reciever function a report with ID \$14 is sent to interface 1:

ReportID	-	2	3	4	5	6	7
\$14 out	enable	\$00	\$00	\$00	\$00	\$00	\$00

enable = \$01 enables the LED function, enable = \$00 disables it again.

Data to be displayed in the matrix is written in 8 rows of 4 bytes each:

ReportID	-	2	3	4	5	6	7
\$15 out	row	data0	data1	data2	data3	\$00	\$00

row denotes the matrix row number. 0 to 7 are valid row numbers. Row number 0 is the data that will be displayed when out1 of the sourcing X driver is active. Row 0, data0 bit 0 is what the programming examples assume to be the upper left corner.

LED Matrix and LCD function can not be used at the same time since they share pins. If one of the functions is enabled it will prevent the other function to get activated.

The LED Matrix function is present in IO-Warrior since chip revision V1.0.2.0. However the initial implementation has some problems when being used with OHCI type USB host controllers. Only V1.0.2.1 and later is recommended for LED matrix use with OHCI host controllers (all Macintosh computers use OHCI, for PCs mainly VIA chipsets are concerned).

# **5.10.7** Switch Matrix Mode (IOW40 only)

IO-Warrior40 can read a matrix of 8x8 or 16x8 switches or keys. Other than with a typical keyboard controller it is possible to read out all possible combinations of closed switches. Since the switch status is reported as a bitmap there is no limitation to the number of switches that can be closed at the same time (diodes are required in the matrix though).

To enable the switch matrix function a report with ID \$18 is sent to interface 1:

ReportID		2	3	4	5	6	7
\$18 out	enable	\$00	\$00	\$00	\$00	\$00	\$00

enable = \$00 disables the function

enable = \$01 enables the 8x8 switch matrix enable = \$02 enables the 16x8 switch matrix

The status of the matrix is returned when ever there is a change of status or it can be requested immediately by sending a report with ID \$19:

ReportID	-	2	3	4	5	6	7
\$19 out	\$00	\$00	\$00	\$00	\$00	\$00	\$00

Since the status of the matrix is 8 or 16 bytes long but the data payload of a report on the second endpoint can be only 7 bytes the status is returned in two or four parts.

Switches on X0..7 driven by Y0..3 are returned in an input report with ID \$19, those driven by Y4..7 are returned in a report with ID \$1A:

ReportID	-	2	3	4	5	6	7
\$19 in	<b>Y</b> 0	Y1	Y2	<b>Y</b> 3	\$00	\$00	\$00

ReportID	1	2	3	4	5	6	7
\$1A in	Y4	Y5	Y6	<b>Y</b> 7	\$00	\$00	\$00

When using the 16x8 matrix size the switches on X8..15 will be returned in reports with IDs \$1B and \$1C:

ReportID	1	2	3	4	5	6	7
\$1B in	<b>Y</b> 0	<b>Y</b> 1	Y2	<b>Y</b> 3	\$00	\$00	\$00

ReportID	-	2	3	4	5	6	7
\$1C in	Y4	Y5	Y6	Y7	\$00	\$00	\$00

On status change or request always all two or four reports will be returned.

The switch matrix function is present in IOW40 since chip revision V1.0.2.0, however the first implementation had a bug that sometimes caused IOW40 to send only one of the two status reports. The problem has been fixed in V1.0.2.1.

The option to use a 16x8 matrix has been added with V1.0.2.6.

# 5.10.8 Capture Timers (IOW24 $\geq$ V1.0.3.0 only)

IO-Warrior24 has two capture timers that allow the measurement of the time between rising and falling edges of a signal. The resolution of the timers is  $4\mu$ sec, the accuracy depends on the USB clock from which IOW24 derives its internal clock with a tolerance of  $\pm 1.5\%$ .

The capture timers use a 24 bit free running counter that gets incremented every 4 microseconds. When a rising or falling edge occurs on a timer input (i.e. the logic level on the pin goes from low to high or from high to low) the value of the counter is stored and send in a report. The relative timing between events can be measured. When reaching maximum count the counter rolls over and starts again from zero. To measure events longer apart than 67.108864s additional time keeping must be done on the host computer.

Two capture timers are available that can be used individually or at the same time. They use the same 24 bit counter, so no timing offset between the two timers exists.

Periodic events up to 250Hz on one timer or up to 125Hz on both timers simultaneously can be tracked with no edges lost, if no other special mode functions of IOW24 are used at the same time. At higher frequencies events can be lost due to overrun (see below).

The maximum frequency for periodic signals that can be handled without IOW24 locking up due to internal overload is above 100kHz (lockup is not permanent when the signal frequency drops IOW24 will resume to work normally). To reliably measure periodic signals faster than a couple 100Hz it is recommended to use an external gating circuit.

Using the LED matrix function or sending/receiving data via IIC during a capture timer measurement can cause the timer value to be corrupted due to too high internal processing load. The capture timers are enabled and disabled by a report with ID \$28 that is sent to interface 1:

ReportID		2	3	4	5	6	7
\$28 out	enable	\$00	\$00	\$00	\$00	\$00	\$00

enable = \$00 disables both timers enable bit 0 = 1 enables capture timer A enable bit 1 = 1 enables capture timer B

Always disable the timers before switching to a different enable state, i.e. if only timer A is in use and you want to activate timer B too, first disable the timers (enable = \$00) before activating both timers (enable = \$03). This applies for all combinations of switching between enable

combinations of the timers.

The capture timers can not be used at the same time as the RC5 receiver. Timer B shares the pin with the IIC function and can not be used at the same time as the IIC function.

Timer data is returned when a rising and/or falling edge was detected on either timer input pin. Timer A uses report ID \$29 to return its data, timer B uses report ID \$2A:

ReportID	1	2	3	4	5	6	7
\$29 in	flags	fall0	fall1	fall2	rise0	rise1	rise2

ReportID	1	2	3	4	5	6	7
\$2A in	flags	fall0	fall1	fall2	rise0	rise1	rise2

flags is a bitfield that signals which edges have been detected and if there was an overrun condition. An overrun occurs if another rising or falling edge is detected on the same timer before the data for the last edge data could be send via USB. IO-Warrior24 can return one data packet every 8msec, this limit applies to the data combined from both capture timers and all other special mode functions of IOW24.

In case of an overrun the first edge that has been detected is reported, subsequent edges are ignored until the data has been send off via USB. There is no guarantee that IOW24 can reliably detect an overrun if the events happen too fast.

The meaning of the flag bits is as follows:

- 7 Capture B rising edge overrun
- 6 Capture B falling edge overrun
- 5 Capture A rising edge overrun
- 4 Capture A falling edge overrun
- 3 Capture B rising edge detected
- 2 Capture B falling edge detected
- 1 Capture A rising edge detected
- 0 Capture A falling edge detected

The report contains data fields for a fall and rise event of the respective timer. The flags indicate if the data is valid, i.e. if the flag for rising edge detected is not set then the rising edge data is not valid.

The flag bits for both timers are always included in both reports.

fall0, fall1, fall2, rise0, rise1, rise2 contain the counter status at the time of the event, xx0 is the least significant byte, xx2 is the most significant byte.

# 6.0 Absolute Maximum Ratings

Storage Temperature	65°C to $+150$ °C
Ambient Temperature with power applied	-0°C to $+70$ °C
Supply voltage on Vcc relative to Gnd	0.5V to +7V
DC input voltage	
Maximum current into all ports (IOW40)	
Maximum current into all ports (IOW24)	70mA
Power Dissipation	
Static discharge voltage	
Latch-up current	

# 6.1 DC Characteristics IOW40

	Parameter	Min	Max	Units	Remarks
V <sub>cc</sub>	Operating Voltage	4.35	5.25	V	
$I_{cc}$	Operating Supply Current		40	mA	
$I_{sb}$	Suspend mode current		20	μA	Oscillator off
I <sub>ol</sub>	Sink current on output pins	7.2	16.5	mA	Vout = 1.0V Port 3
Iol	Sink current on output pins	3.5	10.6	mA	Vout = 2.0V Port 0, 1, 2
R <sub>up</sub>	Pull-up Resistance	4.9	9.1	kΩ	
Vith	Input threshold voltage	45%	65%	V <sub>cc</sub>	All ports, low to high edge
$V_{H}$	Input hysteresis voltage	6%	12%	V <sub>cc</sub>	
	USB Interface				
Voh	Static output high	2.8	3.6	V	15kΩ±5% to GND
Vol	Static output low		0.3	V	
V <sub>di</sub>	Differential Input sensitivity	0.2		V	(D+)-(D-)
V <sub>cm</sub>	Differential Input common Mode Range	0.8	2.5	V	
V <sub>se</sub>	Single Ended Transceiver Threshold	0.8	2.0	V	
Cin	Transceiver capacitance		20	pF	
Iio	Hi-Z State Data Line Leakage	-10	10	μΑ	0V < Vin < 3.3V, Hi-Z State
R <sub>pu</sub>	Bus Pull-up resistance	7.35	7.65	kΩ	7.5kΩ±2% to Vcc
R <sub>pd</sub>	Bus Pull-down resístance	14.25	15.75	kΩ	15kΩ±5%

# 6.1.1 DC Characteristics IOW24

	Parameter	Min	Max	Units	Remarks
V <sub>cc</sub>	Operating Voltage	4.35	5.25	V	
$I_{cc}$	Operating Supply Current		20	mA	
$I_{sb}$	Suspend mode current		25	μA	Oscillator off
I <sub>ol</sub>	Max sink current on output pins		70	mA	Cummulative across all ports
I <sub>ol</sub>	Sink current on output pins		2	mA	Vout =0.4V
R <sub>up</sub>	Pull-up Resistance	8	24	kΩ	
V <sub>ith</sub>	Input threshold voltage	40%	60%	V <sub>cc</sub>	All ports, low to high edge
$V_{H}$	Input hysteresis voltage	3%	10%	V <sub>cc</sub>	
	USB Interface				
Voh	Static output high	2.8	3.6	V	15kΩ±5% to GND
V <sub>ol</sub>	Static output low		0.3	V	
V <sub>di</sub>	Differential Input sensitivity	0.2		V	l(D+)-(D-)l
V <sub>cm</sub>	Differential Input common Mode Range	0.8	2.5	V	
V <sub>se</sub>	Single Ended Transceiver Threshold	0.8	2.0	V	
Cin	Transceiver capacitance		20	pF	
Iio	Hi-Z State Data Line Leakage	-10	10	μA	0V < Vin < 3.3V, Hi-Z State
R <sub>pu</sub>	Bus Pull-up resistance	1.274	15.75	kΩ	1.3kΩ±2% to Vreg
R <sub>pd</sub>	Bus Pull-down resístance	14.25	15.75	kΩ	15kΩ±5%

# **6.2 AC Characteristics IOW40**

	Parameter	Min	Max	Units	Remarks
t <sub>cyc</sub>	input clock cycle time	165.0	168.3	ns	
t <sub>ch</sub>	Clock high time	0.45tcyc		ns	
t <sub>cl</sub>	Clock low time	0.45tcyc		ns	
	USB Driver Characteristics				
$t_{r}$	Transition rise time	75		ns	CLoad = 50pF
t <sub>r</sub>	Transition rise time		300	ns	CLoad = 350pF
tf	Transition fall time	75		ns	CLoad = 50pF
t <sub>f</sub>	Transition fall time		300	ns	CLoad = 350pF
t <sub>rfm</sub>	Rise/Fall Time matching	80	120	%	
V <sub>crs</sub>	Output signal crossover voltage	1.3	2.0	V	
	USB Data Timing				
t <sub>drate</sub>	Low Speed Data Rate	1.4777	1.5225	MBit/s	
t <sub>djr1</sub>	Receiver data jitter tolerance	-75	75	ns	To next transition
t <sub>djr2</sub>	Receiver data jitter tolerance	-45	45	ns	For paired transitions
t <sub>deop</sub>	Differential to EOP transition skew	-40	100	ns	
t <sub>eopr1</sub>	EOP width at receiver	165		ns	Rejects as EOP
teopr2	EOP width at reciver	675		ns	Accepts as EOP
t <sub>eopt</sub>	Source EOP width	1.25	1.50	μs	
t <sub>udj1</sub>	Differential driver jitter	-95	95	ns	To next transition
t <sub>udj2</sub>	Differential driver jitter	-150	150	ns	To paired transition

# **6.3 AC Characteristics IOW24**

	Parameter	Min	Max	Units	Remarks
	clock accuracy	-1.5	+1.5	%	Derived from USB signal
	USB Driver Characteristics				
t <sub>r</sub>	Transition rise time	75		ns	CLoad = 200pF
t <sub>r</sub>	Transition rise time		300	ns	CLoad = 600pF
t <sub>f</sub>	Transition fall time	75		ns	CLoad = 200pF
t <sub>f</sub>	Transition fall time		300	ns	CLoad = 600pF
t <sub>rfm</sub>	Rise/Fall Time matching	80	125	%	
V <sub>crs</sub>	Output signal crossover voltage	1.3	2.0	V	
	USB Data Timing				
t <sub>drate</sub>	Low Speed Data Rate	1.4775	1.5225	MBit/s	
t <sub>djr1</sub>	Receiver data jitter tolerance	-75	75	ns	To next transition
t <sub>djr2</sub>	Receiver data jitter tolerance	-45	45	ns	For paired transitions
t <sub>deop</sub>	Differential to EOP transition skew	-40	100	ns	
teopr2	EOP width at reeiver	670		ns	Accepts as EOP
t <sub>eopt</sub>	Source EOP width	1.25	1.50	μs	
t <sub>udj1</sub>	Differential driver jitter	-95	95	ns	To next transition
t <sub>udj2</sub>	Differential driver jitter	-150	150	ns	To paired transition

# 7.0 Ordering information

Partname	Order Code	Description	Package
IO-Warrior40	IOW40-MOD	IO-Warrior 32 I/O pins, module to replace IOW40-P	DIL40
IO-Warrior40	IOW40-S	IO-Warrior 32 I/O pins	SSOP48
IO-Warrior40 Starter kit	IOW40KIT	Starterkit for IOW40, comes with a IOW40-P and PCB	
IO-Warrior24	IOW24-P	IO-Warrior 16 I/O pins	PDIP24
IO-Warrior24	IOW24-S	IO-Warrior 16 I/O pins	SOIC24
IO-Warrior24 Starter kit	IOW24KIT	Starterkit for IOW24, comes with a IOW24-P and PCB	

The chips listed here are standard products. Customized chips are available on request.

### 7.1 Packaging info

PDIP24 chips come in tubes of 17 each. SSOP48 chips come in tubes of 30 each. SOIC24 chips come in tubes of 31 each.

To assure best handling and shipping safety please order the chips in full tubes if possible.

#### 7.2 USB VendorID and ProductID

By default all IO-Warrior chips are shipped with the USB VendorID of Code Mercenaries (\$7C0 or decimal 1984) and a fixed ProductID.

On request chips can be equipped with the customers VendorID and ProductID. VendorIDs can be obtained from the USB Implementers Forum <www.usb.org>

Customized chips may be subject to minimum order quantities, contact <sales@codemercs.com> for details.

Following are the ProductIDs for the IO-Warrior controllers:

IO-Warrior40 \$1500 IO-Warrior24 \$1501

ProductIDs are independent of the package type.

#### 7.3 Serial numbers

Starting with V1.0.1.0 all IO-Warrior24/40 chips do have unique serial numbers in their device descriptors. These serial numbers can be used to simplify programming for multiple IO-Warriors connected to a single computer.

The serial numbers are factory programmed and

can not be changed. Serial numbers are 8 digit hexadecimal numbers. No two chips of a type will be produced with identical serial numbers. Though it can be that a IOW24 has the same serial number as a IOW40 chip.


It is not possible to order chips with a specific serial number unless they are ordered as custom chips which are subject to minimum order volumes and setup charges.


### 7.4 Currently shipping versions

Following are the currently shipping versions for the chips:


IO-Warrior40	V1.0.3.0
IO-Warrior24	V1.0.3.0
IO-Warrior24PowerVampire	V1.0.2.3
IO-Warrior56	V1.0.0.1

### 8.0 IO-Warrior40 Starter Kit circuit





### 8.1 IO-Warrior24 Starter Kit circuit



### 8.2 Warning about USB cables

The IO-Warrior Starter Kit does ignore one of the USB standard requirements for cables. Contrary to the standard which does not allow detachable cables on low speed devices, IO-Warrior Starter Kit has a B-type plug on the PCB.

As long as a full speed cable according to the USB specs is used this will cause no problems.

If you make your own design based on IO-Warrior do use a captive cable.

## 8.3 Jumpers on the IOW40 Starter Kit

The row of jumpers next to the LEDs (JP1-JP8) can be used to connect or disconnect the LEDs to the pins of port 3. If you intend to use any of these pins for something else you should disconnect the corresponding jumper as the LED would otherwise interfere with the signal.

JP9 next to the switch is used to select the power setting of IO-Warrior (see 5.7). Setting the jumper to the position closer to the switch selects the low power (100mA) mode, the far position selects high power (500mA) mode.

# 8.3.1 Jumpers on the IOW24 Starter Kit

JP1 is used to select the power setting of IO-Warrior (see 5.7). Setting the jumper to the position closer to the IOW24 Chip selects the low power (100mA) mode, the far position selects high power (500mA) mode.

JP2 can be used to disconnect the IR receiver from P0.0.

JP3 can be used to disconnect the LED from P0.3.

# 8.4 Adding custom circuits

The bread board area on the Starter Kit is perfect for adding additional circuits like drivers, opto couplers, etc.

Though you should make sure that this additional circuitry does not interfere with the power restrictions of USB. Make sure to set the power mode jumper JP9 properly so the host is aware of how much power your circuit will draw.

Also your circuit may not draw more than 100mA (including the IO-Warrior itself) before the device is initialized.

IO-Warrior will pull all its pins to a high state on reset and it does so also when entering suspend mode. Your external circuit should be designed so that it drops to a quiscent state when all signals from IO-Warrior go high.


### **8.5** Example circuits

Following are a couple examples for typical circuits you may need.

#### **8.5.1 Drivers**

One of the most common situations will be that the IO-Warrior pin is not capable of sinking a sufficiently high current for the external part you want to control.


Only the pins of Port 3 are powerful enough to drive a LED directly. If you want other pins to drive LEDs or opto couplers you should use the following circuit:



The LED may be the LED of an opto coupler. It may be necessary to adapt the value of the resistor to the LED or optocoupler you use.

LED and resistor may also be replaced by a suitable incandescent lamp.

Driving a relais is very similar, though a diode in reverse direction has to be put parallel to the coil to make sure the discharge of the coil does not damage the transistor and/or IO-Warrior:



The same circuit may be employed if you want to control a DC electric motor. Any inductive load has the bad behaviour of generating a voltage with reverse polarity upon being switched off. If this is not shorted with the diode the voltage will rise to relatively high levels that can damage the driver transistor and/or the IO-Warrior.


Both drivers are active only when the IO-Warrior pulls the port pin low. This makes sure that power consumption is minimized during initialization and suspend mode.

WARNING! If you intend to switch mains voltage with a relais keep in mind that electric shocks at mains level can be lethal. Also faulty circuits with high voltage and/or power are a fire hazard. Such designs or experiments should be done only by properly trained people. Code Mercenaries is not responsible for damage or injury caused by such experimentation.

### 8.5.2 Isolating inputs

In situations where you want to control devices operating on a different power supply than the USB of your computer or where electrical isolation is required for other reasons it is advisable to work with opto couplers.


Opto isolating outputs is discussed in the former paragraph. Opto isolating inputs is similarly simple to achieve:



### 8.5.3 Protecting inputs and outputs

IO-Warrior has a limited protection against electro static discharge in the chip. Though this protection is only sufficient in situations where the electronics is protected inside an enclosure and where the pins are not directly connected to contacts on the outside of this enclosure.

Any pins connected to the outside should have additional protection added to them. In most cases a simple suppressor with two diodes is sufficient:



The diodes will short circuit any input voltages lower than 0V to ground and any higher than supply voltage to +5V.

Usually this is sufficient protection in most environments. If your requirements are higher you should use opto couplers for isolation.

### 8.5.4 Using the LCD function

Just a few components are necessary to connect a HD44780 based display to the IO-Warrior.


One thing you should check first is how much current the display modules draws. If the current does exceed the suspend mode current (see 5.7) you should provide a high side switch to cut the power supply to the display module. The /On signal can be used to enable the power to the display.

Typically HD44780 based display modules have a 16 pin connector that has a standard pinout. However you should in any case check the data sheet of the particular display you want to use to make sure you will not destroy the display due to a different pinout.

Following is the circuit necessary to connect a LCD module with backlighting. This assumes that the display does not draw more power than USB allows for suspend state as the power supply to the LCD is connected direct.

This circuit is already included on the PCB of the IOW24KIT.

## This pinout is for the IO-Warrior 40!



Pot1 is used to set the contrast of the LCD. T1 and R1 drive the power for the backlighting. This circuit is sufficient for displays which have a LED type backlighting.

To access the display the first thing you have to do is enable the LCD special mode function. To do this you send the following report to interface 1:

ReportID		2	3	4	5	6	7
\$04 out	\$01	\$00	\$00	\$00	\$00	\$00	\$00

This will enable the LCD function and pull the /On pin low. The backlight of the display should now be on. A line of dark rectangles should be visible on the display. If this is not the case you may have to adjust Pot1.

Next you need to initialize the display. This depends a bit on the type of display you use and what operating mode you want to put it in.

Lets assume we do have a two line display. We want the display cleared and the cursor displayed as well as a flashing character at the cursor position.

To do this we send the following report:

ReportID	1	2	3	4	5	6	7
\$05 out	\$03	\$38	\$01	\$0F	\$00	\$00	\$00

The \$03 in the flags position tells IO-Warrior to write 3 bytes to the command register of the LCD. \$38 sets the data bus of the LCD to 8 bits and enables two line mode. \$01 is the clear command which empties the display buffer. \$0F enables the display, enables the underscore cursor and the flashing cursor position.

Now we want to display a couple characters. Send the following report:

ReportID	1	2	3	4	5	6	7
\$05 out	\$86	\$41	\$42	\$43	\$44	\$45	\$46

\$86 in the flags tells IO-Warrior to write 6 bytes to the data register of the LCD. The next six bytes are ASCII codes. "ABCDEF" should now appear in the display. Sending the same report again will result in another "ABCDEF" being displayed after the first one.

To access the second line it may be necessary to set the display RAM address first. HD44780 based displays do have storage for up to 80 characters. This storage is divided into two display lines. The first 40 bytes of RAM are used for the first line, data for the second line is in the second 40 bytes. Depending on the actual module characters in the display RAM can end up at different places in the display and not necessarily at places that seem to be logical in the first moment.

For instance a 16x1 display may use display RAM from the second line for the second half of its single display line. Such a display will have to be treated as a two line display even though the user sees only one line.

Displays with four lines typically drive the first and third line from the first 40 bytes in display memory and the second and fourth line from the second 40 bytes.


We recommend to download the HD44780 data sheet from the Hitachi website for more details.

Also there are many information resources on the internet, just use your favorite search engine and look for HD44780.


Attention: When you have an LCD module connected to IO-Warrior you should be aware that the idle status of the IO-Warrior pins may cause the LCD module to assume a valid read going on. So the I/O pins connected to the LCDs data lines may be pulled to a non-zero state.

# 9.0 Package Dimensions

# 40 Pin DIP (discontinued) IOW40-MOD fits on the same footprint




# 48 Pin SSOP




### 24 Pin DIL


# DIMENSIONS IN INCHES MIN. MAX.




	P 13	P 13A
NOTE A	1.170 1.200	<u>1.230</u> 1.260
NOTE B	<u>0.030</u> 0.050	0.060 080.0




# 24 Pin SOIC



DIMENSIONS IN INCHES MIN. MAX.
LEAD COPLANARITY 0.004 MAX.





### 10.0 ESD Considerations

IO-Warrior has an internal ESD protection to withstand discharges of more than 2000V without permanent damage. However ESD may disrupt normal operation of the chip and cause it to exhibit erratic behaviour.

For the typical office environment the 2000V protection is normally sufficient. Though for industrial use additional measures may be necessary.

When adding ESD protection to the signals special care must be taken on the USB signal lines. The USB has very low tolerance for additional resistance or capacitance introduced on the USB differential signals.

Series resistors of  $27\Omega$  may be used alone or in addition to some kind of suppressor device. In any case the USB 2.0 specification chapter 6 and 7 should be read for detailed specification of the electrical properties.

#### **10.1 EMC Considerations**

IO-Warrior uses relatively low power levels and so it causes few EMC problems. The most important issue is to provide a very clean layout for the power supply. IO-Warrior runs at 12MHz internal clock rate, this can cause current spikes if the supply lines are not carefully layed out.

To avoid any EMC problems the following rules should be followed:

- Keep the PCB traces from the resonator to the chip pins as short as possible.
- Put the 100nF ceramic capacitor right next to the power supply pins of the chip and make sure the PCB traces between the chips power pins and the capacitor are as short as possible.
- Run the power supply lines first to the capacitor, then to the chip.
- Connect the second ground pin in the shortest possible way to the first ground pin. No other things may have precedence over this.
- Keep the two USB signal lines close to each other, route no other signal between them. USB uses differential signalling so the best signal quality with lowest RF emission is achieved by putting these lines very close to each other.

### 11.0 Revision History

#### 1.0.3.0

- Added clock stretching handshake and timeout to IIC.
- Added option to deactivate internal pull-ups for IIC on IOW24.

## 1.0.2.6 (no general release)

- Added capture timers to IOW24.
- Added 16x8 key mode to general release.

### **1.0.2.5** Custom chips only, no general release

- Added clearing the buffer for IIC read reports to make the data look better.
- IIC error recovery now sends a Stop signal when no ACK is received after a write. SCL line did stay low after such errors.

# **1.0.2.4** Custom chips only, no general release

#### 1.0.2.3

• Bugfix release for IOW24PowerVampire. It turned out that many service pack levels of Windows XP and 2K have a problem with HID devices that have multiple configurations. This results in a faulty registry entry from which no recovery is possible without user interaction. The solution was to have IOW24PV use a different PID on retry.

No other variants were affected.

#### 1.0.2.2

- Release of IOW24PowerVampire.
- Added 16x8 key matrix mode for cutsom IOW40 chip, not generally released No other variants affected.

#### 1.0.2.1

- Optimized USB code to better work with OHCI hosts. On some Macintosh models situations were observed where the next Setup packet was lost due to too slow handshaking of the last transfer. This lead to transactions to be ignored by IOW24 and IOW40 which then timed out. On IOW40 it could happen that a transaction was properly acknowledged but the data ignored.
  - Any of the above was observed only when the LED matrix function was activated.
- Changed send routine for interface 1 to better cope with fast transmission of data. On IOW40 sometimes the second data packet from the switch matrix was lost.

#### 1.0.2.0

- Added key matrix support to IOW40.
- Added LED matrix support to IOW24 and IOW40.
- Fixed a bug that could cause IO-Warrior to send a stall when receiving the data phase of a SetReport. This was observed only on certain host controllers in combination with Windows XP. The result was lost output reports.

#### 1.0.1.1

• V1.0.1.0 had introduced a minor bug that prevented ports 0 and 1 from generating remote wakeup. For IOW24 this meant it could not generate a remote wakeup at all.

#### 1.0.1.0

- Added serial numbers. This allows unique identification of any IO-Warrior and enables easier support for multiple chips.
- Added GetPinStatus Special Mode Function to get the pin status at any time.
- Added IOW24 variant in DIL24 and SOIC24 package.
- Added SSOP48 package option for IOW40.

#### 1.0.0.3

 Changed endpoint 2 (Special Mode Functions) behaviour to allow reading the last report by GetReport requests. This was necessary as an interim solution to allow proper function with MacOS X.

Instead of reading the interrupt pipe MacOS X is using GetReport requests to access endpoint data. This caused data from Endpoint 2 to be lost. MacOS X 10.3 will fix this.

#### 1.0.0.2

 This is the inital release version of IO-Warrior. Earlier version were used for internal testing only.

# 12.0 Legal Stuff

This document is ©1999-2009 by Code Mercenaries.

The information contained herein is subject to change without notice. Code Mercenaries makes no claims as to the completeness or correctness of the information contained in this document.

Code Mercenaries assumes no responsibility for the use of any circuitry other than circuitry embodied in a Code Mercenaries product. Nor does it convey or imply any license under patent or other rights.

Code Mercenaries products may not be used in any medical apparatus or other technical products that are critical for the functioning of lifesaving or supporting systems. We define these systems as such that in the case of failure may lead to the death or injury of a person. Incorporation in such a system requires the explicit written permission of the president of Code Mercenaries.

Trademarks used in this document are properties of their respective owners.

Code Mercenaries Hard- und Software GmbH Karl-Marx-Str. 147a 12529 Schönefeld OT Grossziethen Germany

Tel: x49-3379-20509-20 Fax: x49-3379-20509-30 Mail: support@codemercs.com Web: www.codemercs.com

HRB 16007 P

Geschäftsführer: Guido Körber, Christian Lucht