AMR PERFORMANCE OPTIMIZATION GUIDE

AMR PERFORMANCE OPTIMIZATION GUIDE

NaviFloor Robotics, Inc.

Document Version: 2.4

Last Updated: January 11, 2024

Classification: Confidential - Internal Use Only

1. INTRODUCTION AND SCOPE

1. This AMR Performance Optimization Guide ("Guide") is a proprieta

2. This Guide applies to all NaviFloor Series X-2000 and X-3000 AMF
2. DEFINITIONS
"Performance Metrics" refers to the quantifiable measurements of A
a) Navigation accuracy (0.5cm)
b) Path optimization efficiency (>95%)
c) Battery utilization rates
d) Load handling precision
e) Surface adaptation response time
2. "Optimization Parameters" means the configurable settings within t
3. PERFORMANCE BASELINE REQUIREMENTS

1. Minimum Performance Standards:
-
Navigation precision: 2cm deviation from programmed path
-
Obstacle detection range: 5.0m at 360
-
Load capacity utilization: 98% of rated capacity
-
Battery cycle efficiency: 85%
-
Surface transition time: 1.5 seconds
2. Environmental Parameters:
-
Operating temperature: 0 C to 45 C

- - 3 -

Humidity tolerance: 10% to 90% non-condensing

-

Floor condition variance: Grade 2 per ASTM F2678

4. OPTIMIZATION PROCEDURES

- 1. Initial Calibration Protocol:
- a) Execute terrain mapping sequence using proprietary LiDAR calibra
- b) Perform multi-surface adaptive testing across all designated opera-
- c) Configure depth-sensing parameters according to facility specificat
- d) Validate navigation mesh accuracy against facility CAD drawings
- 2. Performance Tuning Sequence:
- a) Adjust motion control parameters based on load characteristics

b) Optimize path planning algorithms for facility-specific requirement		
	ath planning algorithms for facility space	sific roquiromonto

- c) Fine-tune surface transition protocols for maximum efficiency
- d) Calibrate sensor fusion parameters for environmental conditions

5. MONITORING AND MAINTENANCE

1. Regular Performance Assessments:

- Daily: Basic navigation and obstacle avoidance tests

- Weekly: Comprehensive performance metric evaluation

- Monthly: Full system optimization review

Quarterly: Firmware update compatibility verification

2. Documentation Requirements:
-
Maintain detailed logs of all optimization activities
-
Record performance metric variations
-
Document all parameter adjustments
-
Archive baseline comparison data
6. SAFETY AND COMPLIANCE
1. All optimization procedures must comply with:
-
ANSI/RIA R15.06-2012 safety standards

- -6-

ISO 10218-1:2011 robotics safety requirements

-

Company safety protocols document REF-SAF-2024-001

2. Safety Override Parameters:

_

Emergency stop response time: 100ms

-

Safety zone monitoring: 360 continuous

-

Human detection sensitivity: Level 4 minimum

7. PROPRIETARY INFORMATION

- 1. This Quide contains confidential and proprietary information of Nav
- 2. Distribution of this Guide is restricted to authorized personnel who

8. DISCLAIMER

- 1. This Guide is provided "as is" without any warranties, express or in
- 2. Implementation of these procedures must be performed by certified

9. VERSION CONTROL

Document Version: 2.4

Release Date: January 11, 2024

Approved By: Dr. Elena Kovacs, Chief Research Officer

Document Control Number: OPT-2024-011

10. EXECUTION

APPROVED AND ADOPTED:

NaviFloor Robotics, Inc.

By: _

Name: Dr. Elena Kovacs

Title: Chief Research Officer

Date: January 11, 2024

