TRAINING MANUAL

TRAINING MANUAL

COLD STORAGE AUTOMATION SYSTEMS

Polar Dynamics Robotics, Inc.

Version 3.2 | Effective Date: January 1, 2024

1. INTRODUCTION AND SCOPE

- 1. This Training Manual ("Manual") contains proprietary and confident
- 2. This Manual is protected under applicable intellectual property laws

2. DEFINITIONS

- 1. "Authorized Personnel" means employees or contractors who have
- 2. "BlueCore(TM) System" means the Company's proprietary cold-en
- 3. "Operating Environment" means temperature-controlled facilities m

3. SAFETY PROTOCOLS

- 1. Pre-Operation Requirements
- a) Verification of BlueCore(TM) system calibration
- b) Environmental temperature confirmation
- c) Safety zone mapping validation
- d) Emergency stop system testing

- 2. Personal Protective Equipment
- a) Insulated safety gloves rated for -30 C
- b) Anti-slip footwear with cold-resistant soles
- c) High-visibility clothing with reflective elements
- d) Cold environment protective gear

4. OPERATIONAL PROCEDURES

- 1. System Initialization
- a) Power-up sequence verification
- b) Navigation sensor calibration
- c) Temperature adaptation period (minimum 20 minutes)
- d) System diagnostics confirmation

- 2. Navigation Parameters
- a) Maximum velocity: 2.0 meters/second
- b) Minimum separation distance: 1.5 meters
- c) Corner approach speed: 1.0 meters/second
- d) Load capacity adjustments for cold conditions
- 3. Emergency Procedures
- a) Manual override protocols
- b) Emergency stop activation
- c) Facility evacuation coordination
- d) System shutdown sequence

5. MAINTENANCE REQUIREMENTS

- 1. Daily₄nspections
- a) Battery charge levels
- b) Sensor cleaning and verification
- c) Mechanical component inspection
- d) Safety system validation
- 2. Weekly Maintenance
- a) Software update verification
- b) Navigation calibration
- c) Motor performance testing
- d) Cold-resistant component inspection
- 3. Monthly Service
- a) Complete system diagnostics

- b) Firmware updates
- c) Battery performance analysis
- d) Mechanical wear assessment

6. TROUBLESHOOTING PROCEDURES

- 1. Error Code Reference
- a) Navigation system errors (NAV-001 through NAV-099)
- b) Power system errors (PWR-001 through PWR-099)
- c) Sensor system errors (SEN-001 through SEN-099)
- d) Communication system errors (COM-001 through COM-099)
- 2. Resolution Protocols
- a) First-level response procedures

- b) Escalation pathways
- c) Emergency support contact information
- d) System recovery procedures

7. CERTIFICATION REQUIREMENTS

- 1. Training Prerequisites
- a) Minimum 2 years industrial automation experience
- b) Cold environment safety certification
- c) Basic robotics systems knowledge
- d) Emergency response training
- 2. Certification Process
- a) Theoretical examination (minimum 80% score)

- b) Practical skills assessment
- c) Emergency response evaluation
- d) Annual recertification requirement

8. LEGAL NOTICES

- 1. This Manual and all related training materials are confidential and p
- 2. Any violation of the procedures contained herein may result in equi
- 3. The Company reserves the right to modify these procedures without

9. DOCUMENT CONTROL

Version: 3.2

Release Date: January 1, 2024

Next Review: July 1, 2024

Document Owner: Technical Training Department

Approved by:

Dr. James Barrett

Chief Robotics Officer

Polar Dynamics Robotics, Inc.

Sarah Nordstrom

Chief Operating Officer

Polar Dynamics Robotics, Inc.

Date: _ 9 _

