

Location of the spare tire, jack and tools

▶ 2WD models



▶ AWD models



- 1 Luggage floor cover
- ② Wheel nut wrench
- ③ Jack

- (4) Spare tire
- (5) Jack handle
- (6) Wheel lock key (if equipped)