# ■ Scanning the first file of all the folders

STEP 1 Press and hold scan until you hear a beep.

The first 10 seconds of the first file in each folder will be played.

STEP 2 When the desired folder is reached, press scan again.

## ■ Selecting from folder lists and file lists

STEP 1 Press PATER IST. .

The folder list will be displayed.

STEP 2 Turn and press to select a folder and a file.

To return to the previous display, press 6 ( • ).

# Selecting and scanning files

# ■ Selecting a file

Turn  $\bigcup_{\text{SNERLLS}T}^{\text{TWE}}$  or press  $\bigcup_{\text{SEEK}}^{\text{TRACK}}$  or  $\bigcup_{\text{SHERLS}T}^{\text{TRACK}}$  to select the desired file.

# ■ Scanning the files in a folder

STEP 1 Press SCAN .

The first 10 seconds of each file will be played.

STEP 2 When the desired file is reached, press scan again.