Displays and buzzers for engine output restriction control and brake control

If the engine output restriction control or brake control operates, a buzzer will sound and a message will be displayed on the multi-information display to alert the driver.

Depending on the situation, engine output restriction control will operate to either limit acceleration or restrict output as much as possible.

Control	Situation	Multi-information display	PKSB OFF Indicator	Buzzer
Engine output restriction con- trol is operating (acceleration restriction)	Acceleration greater than a certain amount is not possible.	"Object Detected Acceleration Reduced"	Not illu- minated	No beep
Engine output restriction con- trol is operating (output restricted as much as pos- sible)	Stronger-than- normal brake operation is nec- essary.	"Brake!"	Not illu- minated	Short beep
Brake control is operating	Emergency braking is necessary.			
Vehicle stopped by system opera- tion (When accelera- tor is stepped on)	The vehicle has been stopped by brake control operation.	"Switch to Brake"	Illumi- nated	Short beep
Vehicle stopped by system opera- tion (When accelera- tor is not stepped on)	The vehicle has been stopped by brake control operation.	"Brake"	Illumi- nated	Short beep