Towing with a wheel-lift type truck

▶ From the front (2WD models)



Release the parking brake.

Vehicles with electric parking brake: Turn automatic mode off. (→P. 225)

▶ From the front (AWD models)



Use a towing dolly under the rear wheels.

▶ From the rear



Use a towing dolly under the front wheels.