# Driving the vehicle

The following procedures should be observed to ensure safe driving:

# Starting the engine

→P. 209, 211

## Driving

- With the brake pedal depressed, shift the shift lever to D. (→P. 217)
- 2 Release the parking brake. (→P. 224, 225)
- 3 Gradually release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.

### Stopping

- 1 With the shift lever in D, depress the brake pedal.
- If necessary, set the parking brake.

  If the vehicle is to be stopped for an extended period of time, shift the shift lever to P or N. (→P. 217)

#### Parking the vehicle

- 1 With the shift lever in D, depress the brake pedal.
- 2 Set the parking brake (→P. 224, 225), and shift the shift lever to P (→P. 217).
- 3 Vehicles without a smart key system: Turn the engine switch to the "LOCK" position to stop the engine. Vehicles with a smart key system:

Press the engine switch to stop the engine.

4 Lock the door, making sure that you have the key on your person. If parking on a hill, block the wheels as needed.

#### Starting off on a steep uphill

- 1 Make sure that the parking brake is set and shift the shift lever to D.
- 2 Gently depress the accelerator pedal.
- 3 Release the parking brake.