(5) Average fuel economy

Displayed item (listed below) can be changed on the fuel economy type screen of \bigcirc . (\rightarrow P. 117)

Total (after reset)

Displays the average fuel consumption since the display was reset.*1,5

■ Tank (after refuel)

Displays the average fuel consumption since the vehicle was refueled.*1,2

- *1: Use the displayed fuel consumption as a reference only.
- *2: When only a small amount of fuel is added to the tank, the display may not be updated.

When refueling, turn the engine switch off. If the vehicle is refueled without turning the engine switch off, the display may not be updated.

- *3: This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.
- *4: The default setting is no display.
- *5: This display can be reset by pressing and holding while it is displayed.

■ Eco indicator

- · Eco Driving Indicator
 - →P. 126
- · Driving range

Displays the driving range with remaining fuel.

When only a small amount of fuel is added to the tank, the display may not be updated.

When refueling, turn the engine switch off. If the vehicle is refueled without turning the engine switch off, the display may not be updated.

This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.