If you think something is wrong



The engine does not start (vehicles without a smart key system)

- Is the shift lever in P? (→P. 209)
- Is the steering wheel unlocked? (→P. 210)
- Is the battery discharged? (→P. 562)



The engine does not start (vehicles with a smart key system)

- Did you press the engine switch while firmly depressing the brake pedal? (→P. 211)
- Is the shift lever in P? (\rightarrow P. 214)
- Is the electronic key anywhere detectable inside the vehicle? (→P. 161)
- Is the electronic key battery weak or depleted? In this case, the engine can be started in a temporary way. (→P. 560)
- Is the battery discharged? (→P. 562).



The shift lever cannot be shifted from P even if you depress the brake pedal

Vehicles without a smart key system:

Is the engine switch in the "ON" position?

If you cannot release the shift lever by depressing the brake pedal with the engine switch in the "ON" position. (\rightarrow P. 221)

Vehicles with a smart key system:

Is the engine switch in IGNITION ON mode?

If you cannot release the shift lever by depressing the brake pedal with the engine switch in IGNITION ON mode. (→P. 221)