## Indicators

The indicators inform the driver of the operating state of the vehicle's various systems.



Turn signal indicator (→P. 223)



Brake hold standby indicator (→P. 229)



Headlight indicator (→P. 231)



Cruise control indicator (→P. 290, 306)



Tail light indicator (→P. 231)



Dynamic radar cruise control indicator (→P. 290, 306)



Headlight high beam indicator (→P. 232)



Cruise control "SET" indicator (→P. 290, 306)



Automatic High Beam indicator (→P. 236)



PCS warning light (→P. 254)



Eco driving indicator (→P. 109, 126)



PKSB OFF indicator (→P. 361)



Parking brake indicator (→P. 224, 225)



LTA indicator (→P. 279)



Parking brake indicator (→P. 224, 225)



LTA indicator (→P. 255, 279)

\*1

Brake hold operated indicator (→P. 229)



LTA indicator (→P. 279)

(If equipped)