Shuffle playback

Pressing (RDM) changes modes in the following order:

Track shuffle \rightarrow Album shuffle \rightarrow Off.

Playing and pausing songs

Press 5 (⊳₪).

Switching the display

Press TEXT.

Each time TEXT is pressed, the display changes in the following order:

 $\mathsf{Track}\;\mathsf{no./Elapsed}\;\mathsf{time}\to\mathsf{Album}\;\mathsf{name}\to\mathsf{Track}\;\mathsf{title}\to\mathsf{Artist}\;\mathsf{name}.$

■ About iPod



"Made for iPod" and "Made for iPhone" mean that an electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards.