4-5.	Using the driving support systems Toyota Safety	
	Sense 2.5+	248
	PCS (Pre-Collision System)	254
	LTA (Lane Tracing Assist)	270
	RSA (Road Sign Assist)	285
	Dynamic radar cruise control with full-speed	
	range	290
	Dynamic radar cruise control	306
	Driving assist systems	
	BSM (Blind Spot Monitor)	
	Intuitive parking assist	
	RCTA (Rear Cross Traffic Alert)	
	RCD (Rear Camera Detection)	
	PKSB (Parking Support Brake)	
	Parking Support Brake function (static	
	objects) Parking Support Brake	300
	function (rear-crossing vehicles)	372
	Driving mode select switches	375
4-6.	Driving tips	
	Winter driving tips	377

5 Interior features

5-1.	Using the air conditioning system and defogger		
	Manual air conditioning system	. 382	
	Automatic air conditioning system (without "SYNC" button)	.387	
	Automatic air conditioning system (with "SYNC" button)	. 394	
	Heated steering wheel/ seat heaters/ seat ventilators		
5-2.		. 402	
-	Interior lights list	405	
	Interior lights		
	Personal lights		
5-3.		. 401	
U-U .	features		
	List of storage features	.409	
	Glove box	.410	
	Console box	.410	
	Coin holder	.410	
	Bottle holders	.411	
	Cup holders	.412	
	Auxiliary boxes	.413	
	Open tray	.414	
	Trunk features	.415	