


5 Remove the light bulb.



6 Install a new light bulb and then install the bulb base to the light unit by inserting it and turning it clockwise.



7 Connect the connector. (When replacing right side bulb only.)



8 Reinstall the trunk lid cover with the clips.

