



- 4 Remove the light unit.
 - 1) Attach a long piece of packing tape to the light unit and fold the excess in half.
 - 2 Hold the folded portion and pull it toward the rear of the vehicle to remove the light unit.



- 5 Turn the bulb base counterclockwise.
- ► Rear turn signal lights







- 6 Remove the light bulb.
- ▶ Rear turn signal lights
- ▶ Rear side marker lights

