Shift position	Meter display	Function	Purpose
+ N S-D		Normal "D" position driv- ing	Gears between "1" and "6" are automatically selected according to driving conditions
	(paddle shift switches activated)	Shift range selection (→P. 163)	Allows opti- mum use of engine brak- ing
+ N S-D	S	Shift range selection (→P. 162)	Allows the driver to select gears for sporty driving