
3-2. Using the audio system

Optimal use of the audio system



- Displays the current mode
- Changes the following setting
- Sound quality and volume balance (→P. 281)

The sound quality and balance setting can be changed to produce the best sound.

- Automatic Sound Levelizer (→P. 281)
- 3 Selecting the mode

Using the audio control function

■ Changing sound quality modes

STEP 1 Press SETUP .

STEP 3 Press ENTER-UST .

STEP 4 Turn to select the desired mode.

"BAS", "TRE", "FAD", "BAL", or "ASL"

STEP 5 Press SCROLL .