

## Wireless remote control

- system
- ▶ Vehicles without a smart key ▶ Vehicles with a smart key sys-





(1) Locks all the doors

Check that the door is securely locked.

2 Unlocks all the doors

Pressing the button unlocks the driver's door. Pressing the button again within 3 seconds unlocks the other doors.

Press and hold to open the windows  $^{\star 1}$  and the moon roof  $^{\star 1,\;2}$  or panoramic moon roof.\*<sup>1, 2</sup> (→P. 180, 184, 188)

<sup>\*1:</sup> This setting must be customized at your Toyota dealer.

<sup>\*2:</sup> If equipped