# **CAUTION**

### To prevent the windshield from fogging up

during cool air operation in extremely humid weather. Do not use

The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.



#### **NOTICE**

## ■To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is stopped.