
SRS curtain shield airbags
Can help protect primarily the head of occupants in the outer seats

SRS airbag system components



- Front impact sensors
- Front passenger occupant classification system (ECU and sensors)
- Knee airbags
- Side impact sensors (front door)
- 5 Side impact sensors (front)
- 6 Front passenger airbag
- 7 Front side airbags
- 8 Curtain shield airbags
- 9 Rear side airbags

- "AIR BAG ON" and "AIR BAG OFF" indicator lights
- SRS warning light
- 12 Front passenger's seat belt buckle switch
- Airbag sensor assembly
- Side impact sensors (rear)
- 15 Driver airbag
- 16 Driver's seat belt buckle switch
- To Seat belt pretensioners and force limiters