MARNING

If you have a flat tire

Do not continue driving with a flat tire.

If you have a flat tire

replaced with the spare tire. For details about tires: →P. 473

Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair, which could result in an accident.

Your vehicle is equipped with a spare tire. The flat tire can be

Before jacking up the vehicle

- Stop the vehicle in a safe place on a hard, flat surface.
- Set the parking brake.
- Shift the shift lever to P.
- Stop the engine.
- Turn on the emergency flashers. (→P. 516)

When trouble arises