## Vehicle exterior

Items	Check points
Doors/trunk	Do the doors and trunk operate smoothly?
Engine hood	Does the engine hood lock system work properly?
Fluid leaks	There should not be any signs of fluid leakage after the vehicle has been parked.
Tires	<ul> <li>Is the tire inflation pressure correct?</li> <li>The tires should not be damaged or excessively worn.</li> <li>Have the tires been rotated according to the maintenance schedule?</li> <li>The wheel nuts should not be loose.</li> </ul>



## ■ If the engine is running

Turn the engine off and ensure that there is adequate ventilation before performing maintenance checks.