# ■ Before programming

- Install a new battery in the remote control transmitter.
- The battery side of the remote control transmitter must be pointed away from the HomeLink® button.

## ■ To prevent battery discharge

Vehicles without a smart key system:

HomeLink<sup>®</sup> will turn off if a door has not been opened and closed for 20 minutes or the engine switch is left turned off. (After which programming cannot be completed.) Open and close a door or turn the engine switch to the "ACC" position to turn HomeLink<sup>®</sup> on. We recommend programming while the engine switch is in the "ACC" position.

Vehicles with a smart key system:

HomeLink<sup>®</sup> will turn off if a door has not been opened and closed for 20 minutes or the "ENGINE START STOP" switch is left turned off. (After which programming cannot be completed.) Open and close a door or turn the "ENGINE START STOP" switch to ACCESSORY mode to turn HomeLink<sup>®</sup> on. We recommend programming while the "ENGINE START STOP" switch is in ACCESSORY mode.

# ■ Certification for the garage door opener

### U.S.A.

FCC ID: CB2051AHL4/CB251AHL4NR

### NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### Canada

### NOTE:

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.