
# 1-4. Opening and closing the windows and moon roof Moon roof\*

Use the overhead switches to open and close the moon roof and tilt it up and down.

### ■ Opening and closing




### Opens the moon roof\*

The moon roof stops slightly before the fully open position to reduce wind noise.

Press the switch again to fully open the moon roof.

- Closes the moon roof\*
- \*: Lightly press the switch in either direction to stop the moon roof partway.

### ■ Tilt up and down



## Tilts the moon roof up\*

- ☑ Tilts the moon roof down\*
- \*: Lightly press either of the moon roof switches to stop the moon roof partway.