
Panoramic moon roof*

Use the overhead switches to operate the panoramic moon roof and electronic sunshade.

Opening and closing the electronic sunshade

- (1) Opens the electronic sunshade
 - Slide and hold the switch backward. The electronic sunshade will fully open automatically.*
- ② Closes the electronic sunshade
 - Slide and hold the switch forward. The electronic sunshade will fully close automatically.*
 - *: Quickly slide and release the electronic sunshade partway.




switch in either direction to stop the

Tilting the panoramic moon roof up and down

Tilts the panoramic moon roof up (press)*

When the panoramic moon roof is tilted up, the electronic sunshade will open to the half-open position of the roof.

*: Lightly press the $\hat{\Leftrightarrow}$ switch again to stop the panoramic moon roof partway.



Tilts the panoramic moon roof down (press and hold)

The panoramic moon roof can be tilted down only when it is in the tilt-up position.

*: If equipped