## SRS side and curtain shield airbags

- ③ SRS front side airbags
  Can help protect the torso of the front seat occupants
- 4 SRS rear side airbags
  Can help protect the torso of occupants in the rear outer seats
- (5) SRS curtain shield airbags
  - Can help protect primarily the head of occupants in the outer seats
  - Can help prevent the occupants from being thrown from the vehicle in the event of vehicle rollover