## Scanning radio stations

## ■ Scanning the preset radio stations

STEP 1 Press and hold scan until you hear a beep.

Preset stations will be played for 5 seconds each.

STEP 2 When the desired station is reached, press scan once again.

## ■ Scanning all radio stations within range



All stations with reception will be played for 5 seconds each.

STEP 2 When the desired station is reached, press scan once again.

## Switching the display

Press TEXT.

Each time TEXT is pressed, the display changes in the following order:

Frequency  $\rightarrow$  Channel name  $\rightarrow$  Radio text.