Removing a child restraint system installed with a seat belt

Press the buckle release button and fully retract the seat belt.

- When releasing the buckle, the child restraint system may spring up due to the rebound of the seat cushion. Release the buckle while holding down the child restraint system.
- Since the seat belt automatically reels itself, slowly return it to the stowing position.

