CTH20BT101US


## Eco-friendly driving information (

## **■** Fuel consumption

- 1 Current fuel consumption
  Displays the instantaneous current fuel consumption.
- Average fuel economy (after start)

Displays the average fuel consumption since engine start.\*1

③ Driving range



(4) Gadget\*4

The following items can be displayed by changing the settings for gadget content and fuel economy type on  $\bigcirc$  ( $\rightarrow$ P. 117)

Displayable item		
Gadget content	Fuel economy type	Content
Average vehicle speed	Trip (after start)	Displays the average vehicle speed since engine start.
	Total (after reset)	Displays the average vehicle speed since the display was reset.*5
Distance	Trip (after start)	Displays the distance driven since vehicle start.
	Total (after reset)	Displays the distance driven since the display was reset.*5
Elapsed time	Trip (after start)	Displays the elapsed time since engine start.
	Total (after reset)	Displays the elapsed time since the display was reset.*5