Item	Function	Default set- ting	Customized setting	1	2	3
Smart key system*1 and wire- less remote control (→P. 32, 46)	Operation signal (Emergency flashers)	On	Off	_	0	0
	Operation sig- nal (Buzzer)	On	Off	_	_	0
	Operation buzzer volume	Level 5	Off to level 7	0	0	0
	Time elapsed before automatic door lock function is activated if door is not opened after being unlocked	60 seconds	Off		0	0
			30 seconds			
			120 seconds			
	Open door warning buzzer	On	Off	_	_	0
Smart key system*1 (→P. 32)	Smart key system	On	Off	_	_	0
	Number of permissible times of continuous smart lock	Twice	Unlimited	_	_	0