Interior features


Some functions can be customized. (→P. 612)



WARNING

To prevent the windshield from fogging up

- Do not use (w) during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.
- Do not place anything on the instrument panel which may cover the air outlets. Otherwise, air flow may be obstructed, preventing the windshield defoggers from defogging.



To prevent burns (vehicles with outside rear view mirror defoggers) Do not touch the rear view mirror surfaces when the outside rear view mirror defoggers are on.



To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is stopped.

When repairing/replacing parts of the air conditioning system Have repair/replacement performed by your Toyota dealer.

When a part of the air conditioning system, such as the evaporator, is to be replaced, it must be replaced with a new one.