
## Multi-information display (7-inch display)

## Summary of functions

The multi-information display presents the driver with a variety of driving-related data, such as the current outside temperature. The multi-information display can also be used to change the display settings and other settings.



- 1 Indicators (→P. 91)
- (2) Driving assist system status display area

Displays the operational status of the following systems:

- Dynamic radar cruise control with full-speed range (if equipped)
  (→P. 290)
- Dynamic radar cruise control (if equipped) (→P. 306)
- LTA (Lane Tracing Assist) (→P. 270)
- ③ Speed limit display (vehicles with a navigation system) (U.S.A. only) /RSA (Road Sign Assist) (if equipped) (→P. 285)
- (4) Clock

For clock settings, refer to "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".

- (5) RSA (Road Sign Assist) (if equipped) (→P. 285)
- (6) Speedometer

The speedometer display can be enabled/disabled in  $\bigcirc$  on the multi-information display. ( $\rightarrow$ P. 117)