# ■ Scanning the first file of all the folders

Press and hold scan until you hear a beep.

The first 10 seconds of the first file in each folder will be played.

STEP 2 When the desired folder is reached, press scan again.

### ■ Selecting a folder and file from folder lists

STEP 1 Press PATER INT .

The folder list will be displayed.

STEP 2 Turn and press to select a folder and a file.

To return to the previous display, press 6 ( \$\square\$).

# Selecting and scanning files

# ■ Selecting a file

Turn  $\circ$  or press  $\circ$  or  $\circ$  to select the desired file.

### ■ Scanning the files in a folder

STEP 1 Press SCAN .

The first 10 seconds of each file will be played.

STEP 2 When the desired file is reached, press scan again.