■ Indicators

The indicators inform the driver of the operating state of the vehicle's various systems.



Turn signal indicator (→P. 166)



BSM outside rear view mirror indicators (→P. 208)



Headlight high beam indicator (→P. 188)



Headlight indicator (→P. 185)



Slip indicator (→P. 203)



Tail light indicator (→P. 185)



VSC OFF indicator (→P. 204)



Front fog light indicator (→P. 192)



"TRAC OFF" indicator (→P. 204)



SRS airbag on-off indicator (\rightarrow P. 113)



Security indicator (→P. 92, 95)



Cruise control indicator (→P. 199)

Type A



Shift position and shift range indicators (→P. 155)



Cruise control set indicator (\rightarrow P. 199)

Type B



Shift position and shift range indicators (→P. 155, 159)



Eco Driving Indicator Light (→P. 136)



Smart key system indicator (→P. 148)