
## The headlights can be operated manually or automatically.

Turning the end of the lever turns on the lights as follows:

## U.S.A. (type A)



- DRL The daytime running lights turn on.
- The side marker, parking, tail, license plate, daytime running lights and instrument panel lights turn on.
- The headlights and all the lights listed above (except daytime running lights) turn on.
- OFF The daytime running light turns off.