Toyota parking assist monitor"	U
Toyota Safety Sense 2.5+ 248	USB charging port418
Automatic High Beam236	USB memory*
Dynamic radar cruise	USB port*
control306	
Dynamic radar cruise control	V
with full-speed range 290	Vanity lights 416
LTA (Lane Tracing Assist) 270	Vanity hights
PCS (Pre-Collision	Vanity lights
System) 254	Vehicle data recording9
TRAC (Traction Control) 322	Vehicle identification
Traction Control (TRAC) 322	number576
Trailer towing207	Vehicle Stability Control
Transmission	(VSC) 322
Automatic transmission217	Voice command system*
Driving mode select	VSC
switches375	(Vehicle Stability Control) 322
If the shift lever cannot be	(Vehicle Stability Control) 322
shifted from P221	
Paddle shift switches219	W
S mode218	Warning buzzers
Trip meters 94	Approach warning 299, 315
Trunk156	Brake system528
Grocery bag hooks415	Downshifting220
Internal trunk release lever 158	Electric power steering
Smart key system156	system530
Trunk light158	Intuitive parking assist 339
Trunk opener156	Key reminder 210
Wireless remote control 157	Lane departure alert
Trunk light	function 275
Trunk light158	Light reminder234
Wattage 589	Open door 154
Turn signal lights	Open hood457
Replacing light	Open moon roof 185
bulbs503, 509, 512	Open panoramic
Turn signal lever223	moon roof 189
Wattage589	Open trunk158
	Parking brake 529
	Pre-collision warning 254
	RCD
	(Rear Camera Detection) 354
	Seat belt reminder 531
	Vehicle sway warning 277